

How to use control air conditioner Gree 1-way, 2-way simple, most detailed

How to understand the symbols and functions on their remote, not everyone can grasp. To help you more convenient in the use process, in this article, TipsMake.com will share how to use the simplest, most detailed Gree air conditio

Gree air conditioner is a very popular device in Vietnam market. However, to understand the symbols and functions on their remote, not everyone can grasp. To help you more convenient in the use process, in this article, TipsMake.com will share how to use the simplest, most detailed Gree air conditioner control. Let's follow you guys!



Things to note before using Gree air conditioner

Like many other air conditioner brands on the market, Gree air conditioners also have many models, so their remotes are also quite diverse. In this article, we will focus only on how to use the most common Gree control, and with the other controls, you can apply the same.

In addition, during use, you should also pay attention to storage controls in a cool place, avoid direct sunlight, limit dropping.

If the controller runs out of battery, you need to replace the battery immediately and replace 2 batteries at the same time for the best operation.

Learn the function buttons on the Gree air conditioner controller

Meaning of the buttons on the Gree air conditioner remote

1. **ON / OFF button** : Turn on / off the air conditioner.
2. **MODE button**: Button to adjust the modes of the machine.
3. **FAN button**: Adjust the speed of the fan.
4. **TURBO button** : Acceleration button helps to quickly regulate the set temperature.
5. **? button** : Temperature rise button.
6. **? button** : Temperature reduction button.
7. **SWING button** : Turn on / off the inverse function.
8. **SLEEP button** : Good sleep mode, help you get the most comfortable feeling without getting cold when sleeping.
9. **TEMP button** : Display temperature button.
10. **I FEEL button**: The button has the function of sensing the remote position from which to adjust the temperature accurately at that position.
11. **CLOCK button**: Adjust the clock button displayed.
12. **LIGHT button**: Light button.
13. **Button TIMER ON** : Timer to turn on the machine.
14. **Button TIMER OFF** : Timer shutdown.

The basic operating mode of Gree air conditioner

1. **AUTO mode (automatic)** : When the machine operates in this mode, you will not be able to adjust the temperature, you can only adjust the fan blowing speed and speed only.
2. **COOL mode (cooling)** : You will get the most comfortable feeling when using this mode because the machine will condition the air to cool the room and you can also adjust the temperature as well as fan speed.
3. **DRY (drying) mode** : The moisture in the room will be removed to help the space be dry, cool.
4. **FAN (fan) mode**: The machine will both chill and combine with the reversing fan to keep the room air open.
5. **HEAT (heating) mode** : This mode is only available in Gree 2-way air conditioners.

Instruction manual Gree air conditioner details

General operating mode of Gree air conditioner

1. **Step 1** : Press the ON / OFF button to start the air conditioner.
2. **Step 2**: Press the MODE button to select the mode according to user needs, including: AUTO, COOL, DRY, HEAT and FAN.

How to change the direction of the air reversal up / down

When selecting this mode, you will be able to adjust the airflow direction so that it best suits your needs.

When the machine is in operation, you press the SWING button to change the flap up or down. The directions of the flaps are displayed on the remote screen as below:

How to change the fan speed

You can adjust the fan speed to the levels from low to high according to your desire by following these steps:

1. **Step 1:** Press the ON / OFF button to start the device.
2. **Step 2:** Press the FAN button to select the desired fan speed.

Note: In AUTO mode, the machine will automatically select fan speed in accordance with the ambient temperature. In DRY mode, the device will not adjust the fan speed.

Activate fast cooling mode

This feature is especially useful on hot hot days. If you want to quickly feel the cool breeze when coming in from outside, do the following:

1. **Step 1:** Press the MODE button and select COOL mode.
2. **Step 2 :** Press the TURBO button. At this time, the air conditioner will quickly cool the room. As soon as the room is cooled at the set temperature, this feature will automatically disconnect to save the most energy efficient.



Enable temperature sensor

This is a smart feature of Gree air conditioner. It supports the chiller at the temperature set by the user. The remote will have a built-in sensor to sense the temperature around the area and the machine will cool according to this temperature level.

To enable this feature, do the following:

1. **Step 1** : Press the I FEEL button, then the machine will automatically detect the location of the remote and adjust the temperature exactly where the remote control is.
2. **Step 2** : Press I FEEL again to turn off this feature.

How to set the time

1. **Step 1**: Press the CLOCK button to set the timer.
2. **Step 2**: Press the ? or ? button to adjust to increase / decrease the time.

How to set the timer

Before you want to set a timer, be sure to set the correct time for the air conditioner.

1. **Step 1** : Press the TIMER ON button to activate the timer to turn on the machine or TIMER OFF to enable the timer to turn off the machine.
2. **Step 2**: Press the ? or ? button for 5 seconds to increase / decrease the timer.
3. **Step 3**: Press the TIMER ON or TIMER OFF button respectively to confirm.
4. **Step 4**: Press the TIMER ON or TIMER OFF button twice within 5 seconds to cancel the timer.



How to turn on / off the light shown on the screen

LED lights on the indoor unit will sometimes interfere with your sleep, you can turn them off by pressing the LIGHT button on the remote.

Note to use Gree air conditioner to save electricity

A few notes below will help you save quite a bit of electricity costs monthly.

1. It is recommended to use a humidifier, air-conditioning fan or electric fan in air-conditioned room to increase cooling effect, and at the same time does not cause dry skin, dry nose.

2. Should turn on the air at low temperatures for about 10-15 minutes, then adjust to the appropriate temperature (about 25 - 27 degrees C).
3. Regularly clean the room, arrange the objects in the room neatly so that the cooling effect is increased.
4. Clean, maintain air conditioning regularly.
5. Do not use the air conditioner all day.

You finished reading the article "**How to use control air conditioner Gree 1-way, 2-way simple, most detailed**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.