

10 extreme tricks or anyone should know when using Galaxy J7 Prime

Samsung Galaxy J7 Prime phone is considered a destroyer in the mid-range segment, is very hot recently. If you own this phone, some of the following helpful tips will help you.

Recently, Samsung has unveiled a new phone market, which is considered a "destroyer" in the mid-range segment, which is Samsung Galaxy J7 Prime. This smartphone has an eye-catching design with a monolithic metal body and the latest one-touch fingerprint sensor. If you own a Samsung Galaxy J7 Prime, here are some tips to help you get used to this phone easily.

1. How to download Youtube videos on Samsung J7 Prime phone

1. How to take photos of Samsung Galaxy J7 Prime phone screen

1. 3 ways to take screenshots on Samsung Galaxy Note 4



Just like your Galaxy siblings, to take screenshots on Samsung Galaxy J7 Prime phone, you just need to press and hold the **Home + Power** key **at the same time to capture** . After that, the photo will be automatically saved to the photo library, if you want to view the photo you just need to access the photo library.

2. Simple mode on the phone



70% 01:06 PM

Cài đặt

TÌM KIẾM

-  Màn hình nền
-  Theme
-  Màn hình chờ
-  Màn hình khóa và bảo mật
-  Riêng tư và an toàn
-  Chế độ Đơn giản
-  Hỗ trợ
-  Tài khoản
-  Sao lưu và cài đặt lại



-  Ngôn ngữ và bàn phím
-  Pin



Simple mode is a mode that makes it easy for users to use the device with the simplest icons and effects. If you want to enable this mode to use it, just go to **Settings => Simple mode => The screen will show two options: Standard mode and Simple mode, select Simple mode => Click Finish**, it's done.

3. Delete an application data on Samsung Galaxy J7 Prime phone


If you want to reset an application without having to remove this application, users can proceed to delete the application data. And this operation on Samsung Galaxy J7 Prime proceeds as follows:



70% 01:05 PM


Cài đặt

TÌM KIẾM

 Quản lý Thông minh

 Ứng dụng

 Âm thanh và rung

 Thông báo

 Không làm phiền

 Màn hình

 Màn hình cạnh


 Tính năng nâng cao

 Màn hình nền

 Theme

 Màn hình chờ





- Go to **Settings** and select **Applications** then go to **Application Manager** .



17% 11:11

← Thông tin ứng dụng



Dan The Man

Phiên bản 1.0.7

GỠ CÀI ĐẶT

BUỘC DỪNG

Bộ nhớ

Đã dùng 120 MB trên Bộ nhớ thiết bị

Sử dụng dữ liệu

Đã dùng 1,12 MB kể từ 26 Th10

Quyền

[Không cần cấp quyền](#)

Thông báo


[Cho phép](#)

Đặt làm mặc định

[Chưa đặt ứng dụng nào làm mặc định](#)

Pin

Đã dùng 0% từ lần sạc đầy cuối cùng



-At the **Application Management** page, select the application where you need to delete the data and then select **Delete data** .

4. Change the wallpaper in the message

If you feel too bored with the default interface in the Messages section of your phone, you can also change the new shirt for this item in your own style. To enable this feature, do the following:



Tin nhắn


NHIỀU HƠN



Chạm để thêm người gửi ưu tiên.



Không có tin nhắn





First turn on the **Messages** application, click **More** then select **Settings** .



← Cài đặt tin nhắn

Thông báo

Bật

Nên

Phản hồi

Chặn tin nhắn

Nhiều cài đặt hơn





Here, select **Background** , but according to the user's liking, to select the appropriate background image.

5. Delete Google account

To delete or log in a new account to your Google account on Samsung Galaxy J7 Prime phone, you can follow the instructions below:



Riêng tư và an toàn



Chế độ Đơn giản



Hỗ trợ



Tài khoản



Sao lưu và cài đặt



Ngôn ngữ và bàn phím



Pin



Bộ nhớ



Thời gian




Sách hướng dẫn sử dụng



Thông tin thiết bị





If you want to add a new account, go to **Settings**> **Accounts**> **Google** and select Add account to add a new account.

← Google


NHIỀU HƠN



savina.fpt.kg@gmail.com

Google






If you want to delete an account, select **More > Delete account** .

6. Connect your phone to the computer

1. Ways to connect Android phones to Samsung TVs



If you need to copy data from your phone to your computer, you just need to plug the connection cable between the phone and the computer together. Now the computer will automatically connect to the phone and display the hard drive with the phone icon image, click here and open up to be able to 'copy-paster' data from the phone to the computer or opposite.

7. Customize network mode

Adjusting this network mode helps J7 Prime users to adjust 4G, 3G or 2G network modes that users want.



Bluetooth



Chế độ Máy bay



Chia sẻ kết nối internet



Sử dụng dữ liệu



Quản lý SIM



Các mạng di động



Cài đặt kết nối khác



Quản lý Thông minh



Ứng dụng



Âm thanh và rung



Thông báo

← Các mạng di động

Chuyển vùng dữ liệu

Sử dụng dữ liệu di động khi đang chuyển vùng có thể phát sinh thêm phí.




Chế độ mạng

LTE/3G/2G (tự động kết nối)



Điểm truy cập

Nhà cung cấp mạng



Make settings as follows: **Select Settings> Mobile networks> Network mode** . The screen will display the list of networks, selecting the network you want to install is complete.

8. Link OTG on Samsung J7 Prime



On Samsung Galaxy J7 Prime has OTG connection function with computer mouse and keyboard to help users manipulate extremely convenient.

It is essential that you need an OTG cable to plug into the charging port on the phone.

There are many types of power cord on the market such as:

- Connect with computer mouse: Plug the USB mouse into the other end of the OTG cable.

Actions on the mouse are as follows: Right mouse equivalent to back button. Right mouse button is selected.

- Connection to the keyboard: Manipulating to connect the same way as the computer mouse, after connecting, you can freely manipulate the phone via the computer keyboard. This connection allows you to easily release text or text messages on your phone using the keyboard.

- USB connection: J7 Prime allows you to connect to USB via OTG, from here you can easily backup data from phone to USB for storage or vice versa.

9. Take a picture with the volume up / down key

Instead of clicking on the capture button as usual, you can take a picture via the volume button. This is an extremely convenient feature for selfie lovers. To activate this mode, you only need:

Kích thước video (sau)

FHD 1920x1080

Đường lưới

Tắt

Tag vị trí

Đính kèm, nhúng và lưu dữ liệu vị trí địa lý trong mỗi bức ảnh và video.



Xem lại ảnh

Xem ảnh ngay sau khi chụp.



Khởi động nhanh

Mở Máy ảnh bằng cách nhấn nhanh phím Trang chính hai lần.



Chức năng của phím âm lượng

Chụp ảnh



Xóa các cài đặt



Start Camera, select Settings and then set up the Function of the volume key> Take a picture.

10. Quick start the camera





With the quick start-up camera setting that allows users to take photos on Samsung Galaxy J7 Prime just press the Home key twice as the photography application has opened.

Install as follows: **Open Camera => Settings** select **Quick start** .

These are 10 cool tips for Galaxy J7 Prime users. Hope you will discover many interesting things on this great phone.

Good luck.

See more:

1. Interesting tips when using smartphones everyone should know
2. 11 tips for Android phones
3. 8 tips for maximum battery saving for your phone

You finished reading the article "**10 extreme tricks or anyone should know when using Galaxy J7 Prime**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.