

# 10 milestones of regular maintenance help cars always in the best condition

Here are the milestones or the time that car owners need to know to periodically change engine oil, air filter, brake pads, wiper ... for cars.

Periodic maintenance is extremely important to help cars maintain longevity and ensure safe operation. Here are the milestones or the time that car owners need to know to periodically change engine oil, air filter, brake pads, wiper . for cars.

## **1. Maintenance of motor vehicle engines for new vehicles: 3,000 km / time**

According to experts, the car just bought about 3,000 km or after 3-4 months of domestic use needs to be maintained so the car engine will be best cared for in the first time.

## **2. Electric power steering system: 50,000km / time**

Like other engine systems, hydraulic power steering system needs to be maintained, cleaned, and changed water to increase the life and safety of cars.

## **3. Changing brake fluid: about 2 years / time**



Corrosion and performance of brakes on vehicles must be checked according to the time specified by the company. However, to ensure the best performance of the brakes, avoid unnecessary accidents that the vehicle owner should replace and check the brake fluid every 2 years.

#### **4. Sanitation of cooling system: every 3 years**

After 2-3 years, the car's cooling system will release a toxic substance that can corrode the exhaust pipes. Therefore, car owners should clean the cooling system on the car periodically to improve cooling performance and protect the battery.

#### **5. Changing automatic transmission oil: 50,000 - 100,000km**

With normal driving conditions, automatic transmission oil should change every 70,000 - 80,000 km. And in harsh driving conditions, should change early about 50,000 - 70,000km.

#### **6. Changing gearbox oil: 50,000 km / time**

Gearbox oil should be replaced every time the vehicle is moved 50,000 km. Gearbox oil is often provided by the car manufacturer, so the car owner should bring the car to the company to replace the right type of oil or use the type of oil recommended by the company.

#### **7. Changing the engine air filter: 30,000 - 40,000 km / time or from 3 years**



As recommended by the car manufacturer, should change the air filter every 30,000 - 40,000km / time or from 3 years. However, the time to change the engine air filter depends on the changing environmental conditions, going into dust areas for roads or constructions. Therefore, when performing periodic maintenance, the air filter check is too dirty to replace immediately to increase the performance of the engine.

## **8. Cooling water: 80,000 - 100,000km**

Water will cool deposits, degeneration, not good for the apparatus after a period of operation. Therefore, car owners should pay attention to change engine coolant in the range of 80,000-100,000km.

## **9. Driving belts: 70,000 - 100,000km**

In the range of 70,000 - 100,000 km, should replace the driving belts. Car owners should also pay attention to checking the transmission system regularly to see if the belt is cracked, broken or not to replace it promptly, especially in hot weather.

## **10. Spark plugs: 30,000 - 40,000 km**

Spark plugs are quickly eroded due to frequent impacts. Therefore, after nearly 2 years or about 30,000 - 40,000km you should replace it.

You finished reading the article "**10 milestones of regular maintenance help cars always in the best condition**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.