

13 good tips and tricks when using Galaxy Smartwatch

Its Galaxy smartwatch line supports both Android and iPhone, reliable, equipped with many useful hardware and software features.

You may be surprised that Samsung is constantly making a name in the smart watch market. Its Galaxy smartwatch line supports both Android and iPhone, reliable, equipped with many useful hardware and software features.


However, even if you own one of these Galaxy smartwatches, it is possible that you still have not taken full advantage of this device. These wearable devices contain countless little-known abilities. Here are the best tips and tricks to make the most of your Samsung Galaxy smartwatch.

These exciting features on Samsung Galaxy Smartwatch

1. 1. Customize the watch face
2. 2. Rearrange widgets, quick settings and apps
3. 3. Take a screenshot
4. 4. Personalize the shortcut to double the Home button
5. 5. Modify the background for the entire system on the clock
6. 6. Add music tracks and images offline
7. 7. Avoid accidentally stroking and pressing while swimming
8. 8. Connect to the remote meter
9. 9. SOS configuration
10. 10. Stop receiving the same message twice
11. 11. "Clean up" the memory of the clock
12. 12. Try Goodnight, Theater and Watch-Only modes
13. 13. Sideload application on smartwatch

1. Customize the watch face

3:48



Galaxy Watch Active



Customise



Breathe



Fit future



Pie twirl



Activity sparkles



Pop analogue



Peak time



Solar board



My day



Health dashboard




Home

Watch faces

Discover





Samsung's Galaxy Store stores a lot of watch faces that you can try. But you may want a specific element, such as choosing a different color or replacing it with a complication utility.

Fortunately, you can customize the watch face (depending on the developer). For example, you can modify part of most of the available Samsung watch faces. These allow you to change designs, text colors, etc. If you don't like any of the pre-installed options, you can find and consult some great Samsung Gear watches. other great on the Internet.

The **Customize** button , if available, will appear at the top of the **Watch Faces** tab on the Galaxy Wearable application. Make sure you have it installed to make the most of the tips of this article.

[Download Galaxy Wearable for Android | iOS \(Free\)](#).

2. Rearrange widgets, quick settings and apps

3:49



< Reorder

App order

- Most recent first
- Custom


Customise app order

- Recent apps
- Phone
- Contacts
- Bixby
- Samsung Health
- Galaxy Store
- Settings
- Weather

Cancel

DONE





Navigating on a cramped touch screen like smartwatch may be just a chore. But you can still speed up your usual interactions a bit by rearranging widgets, quick settings and apps.

On the companion app, you can arrange these elements to quickly access the services you access the most. To edit the app drawer order, open the Galaxy Wearable app and go to **Apps> Menu> Reorder** .

Here, you can let the clock automatically push your most used applications to the top of the list or change the order by holding a specific application and dragging it.

To do the same for widgets, open the **Widgets** panel in the Galaxy Wearable app. You can also personalize quick settings from **Advanced> Edit Quick Settings** .

3. Take a screenshot

Did you know that you can take screenshots of your smartwatch? This can be useful, especially for troubleshooting purposes, when you may need to share the error message with the support team.

To take a screenshot on Samsung Galaxy smartwatch, swipe from left to right while holding the **Home** button . If successful implementation of this gesture, you will see an animation of the screen shot leaving the screen.

The screenshots do not transfer directly to your phone. Instead, they are stored on the watch's local storage until you move them yourself.

To do that, go to the **Gallery** app on the watch. Click on the screenshot and select the three dots menu. Now, select **Send to Phone** and you will receive a notification on your phone after the transfer is complete.

4. Personalize the shortcut to double the Home button

3:49



< Advanced

Double press Home key

Music

Wake-up gesture

On



Touch wake-up

On



Water lock mode

Off

Touch sensitivity

Off



Do not disturb

Off



Theatre mode

Off



Good night mode

Off




Edit quick settings

Screen capture

On





Another method to launch immediately your favorite smartwatch application is to use the shortcut to double the Home button. You can assign it to any application on the watch, as well as essential actions such as going to the last application you used, creating reminders and viewing recent applications.

Installation is in the Galaxy Wearable application in **Advanced**> **Double press Home key** .


5. Modify the background for the entire system on the clock

3:50



< Display

Brightness



Auto low brightness

On



Screen timeout


10 seconds

Show last app

Within 20 seconds

Background style





By default, Samsung's smartwatch, which has a full dark background. But you can change it, if you don't like it. You can easily change another option from the companion application. You will find the background settings in **Display > Background Style** .

However, at the time of writing, the watch does not allow the use of custom images. You can only choose from some pre-packaged gradients.

6. Add music tracks and images offline

3:50



< **Add content to your watch**

Music

Add tracks

Auto sync

Sync recently added tracks with your watch automatically.



Images

Copy images

Auto sync

Sync images from selected albums with your watch automatically.




Image limit

200

Albums to sync

Camera





Like your phone, Samsung Galaxy smartwatch has some local memory. You can take advantage of this by adding music and images to the watch for offline viewing. For example, this allows you to jog without a phone and listen to music through a wireless headset, right on your smartwatch.

To add content to the watch, first open the Galaxy Wearable application. Click **Add Content to Your Watch** and select **Add Tracks** or **Copy Images** . You can even turn on **Auto-Sync** to always keep the clock synchronized with the data on your phone.

7. Avoid accidentally stroking and pressing while swimming

Samsung's latest smart watch can track your swim times, as well as call or text contact numbers. However, you probably don't want to combine these two features.

To avoid accidentally calling someone or performing any other unwanted action while swimming, you should turn on **Water Lock** mode . Basically, this mode puts your watch in a locked state and prevents any accidental contact from happening when you are underwater.

Activate Water Lock mode by clicking the water drop icon in quick settings.

8. Connect to the remote meter

3:51



< Account and backup

Samsung account


imshubhagr@gmail.com

Back up and restore

Remote connection

Use your Samsung account to connect to your watch remotely using Wi-Fi or mobile data.





The presence of LTE and / or WiFi allows your Samsung smartwatch to remotely connect to the phone. Therefore, you do not need to pair your devices via Bluetooth at all times. The remote connection also allows you to locate your watch even if it's out of range of 'communicating' with the phone.

To enable this function, go to **Account and Backup > Remote Connection** .

9. SOS configuration

3:52



< Send SOS requests

Off



Your emergency contacts will receive SOS messages with your current location.




Send SOS messages to

No recipients added

Count down before sending

Wait 5 seconds before sending SOS requests to allow them to be cancelled.





The Samsung smartwatch can transmit SOS requests in an emergency. However, this feature is not enabled by default. To configure, navigate to **Send SOS Requests** in Galaxy Wearable application. Turn on the first option and add the people you want to contact when you press the **Home** button three times in a row.

When performing this combination operation, the clock will send a message to the emergency contacts that you have selected with your location coordinates. In addition, you can enable the countdown feature to make sure the clock does not mistakenly send SOS requests.

10. Stop receiving the same message twice

Whenever you receive a notification, both your watch and phone will ring. You can change this behavior and terminate duplicate commands.

Galaxy Wearable application can mute the notification on the phone while you wear the watch. The settings are available in the **Notifications** section of the companion application.

11. "Clean up" the memory of the clock

3:53



< Storage



System and apps: 2.6 GB
Unnecessary data: 0.2 MB
Available space: 1.4 GB

Free up storage space by deleting unnecessary data, such as cached, residual, and advertisement files.

CLEAN NOW



Images

0.44MB



Audio


5.43MB



Apps and watch faces

349.7MB





When used for a long time, a lot of cache files can be "piled up" on your watch, making the memory block. The remaining memory is very small if there are many applications running. Thankfully, you can easily clean them from the companion application.

All you need to do is touch the storage ring or memory on the main screen of the application, then press the **Clean Now** button .

12. Try Goodnight, Theater and Watch-Only modes

3:54



< Good night mode

Off



Prevent disturbances while you're sleeping.
Your watch won't light up or vibrate for alerts except for
alarms and notifications.
Turn off Watch always on and Wake-up gesture.





Samsung includes a number of handy modes on its smartwatch, for situations like when in a movie theater or sleeping. In addition to the regular **Do Not Disturb** mode, there are three other silent profiles you should try out as **Good Goodnight**, **Theater** and **Watch-Only** .

In **Theater** mode , **your** watch will not light, vibrate or ring when there's a new warning. **Goodnight** mode is almost the same, with one exception. It keeps everything quiet except the alarm.

Finally, the **Watch-Only** mode is for when the smartwatch battery is already extremely low. It turns off all the clock sensors and only displays the time. Samsung claims the Watch-Only mode can help the smartwatch's battery life last 2 or 3 days longer.

You will find options for Goodnight and Theater mode in quick settings. To turn on the Watch-Only configuration, touch the **Battery** icon in the quick setting, scroll down and activate the Watch-Only mode.

13. Sideload application on smartwatch

Even more awesome, Samsung lets you sideload watch faces and apps on Galaxy smartwatch. However, before that, you need to enable an option in the settings.

Open the Galaxy Wearable application and in the **Advanced** section , you will see **Install Unknown Apps**. Be cautious when installing applications from other sources.

These tips and tricks will help you use your Samsung Galaxy smartwatch in creative ways you may not have known before. There are many things you can do on smartwatch by exploring its app store.

Hope you are succesful.

You finished reading the article "**13 good tips and tricks when using Galaxy Smartwatch**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.