

5 main reasons why the refrigerator is watery - How to fix it

The refrigerator is watery, or sweaty, making the ability to store food worse. There are many reasons for this situation and these are the main causes of refrigerator water runoff and the quickest fix.

A leaking refrigerator is a common phenomenon in old or used cabinets for a long time. However, if your family just bought a refrigerator and encountered this situation, please read the article below to find out the cause and how to fix it!



Why is the refrigerator watery? How to fix?

1. Flowing to the floor from the water tray behind the refrigerator


Cause: The water drain pipe breaks the ice in the refrigerator

This is one of the main causes of water leakage inside the refrigerator. This happens when dirt or food, objects get caught inside and clogs the drainage pipe, leading to a buildup of ice and water leakage in the refrigerator.



How to fix:

First, you must unplug the refrigerator to ensure safety during repair. After that, check if the tube is folded, blocked or punctured. You can try by flushing the inside of the refrigerator with warm water through a small funnel. Then, use a dust collector or plastic hook to remove dirt in the pipe. If this doesn't fix the problem, you'll have to remove the pipe to clean the pipe.



Cause: The refrigerator water tray is cracked

Sometimes, water trays may crack, which may cause the refrigerator to leak.

How to fix:

You consider whether the water inlet is cracked or if there is a dent. If so, you need to call a repairer for warranty and replacement.



>>> Refer to: "Why is your refrigerator getting sweating, stagnant? How to fix it?"

2. Run water in the cool compartment

Cause: Leaking water from the vegetable tray

Fruit and vegetables when bought later in the rainy days have a lot of water accumulated. Since you buy food and put it right into the refrigerator, water leaks from fresh food such as vegetables, tubers, fruits . making the vegetable container watery. This not only affects the shelf life of the refrigerator but also makes the vegetables very susceptible to waterlogged or rotten.

How to fix:

Check the food in the cupboard and remove it, pour the water and clean the vegetable compartment. Allow the food to drain off the fresh water and put it in the refrigerator.

Cause: Block the ventilation system in the refrigerator

Stuffing too much food into the refrigerator compartment will block the airway between the cooler and the freezer. The electrical system is responsible for controlling broken refrigerators, melting ice and causing water leakage.

How to fix:

Check the ventilation (cold vent holes) on the two refrigerator compartments with your eyes to see if they are sealed. Arrange food in the refrigerator properly. Do not store too much food in the cupboard.

You can refer to the article: "How to arrange and manage reasonable food in the refrigerator" to help the food be preserved longer, the ability to cool more efficiently and help save energy.



3. Flowing from the freezer

Cause: The door of the freezer is open or the cooling mode has a problem

The freezer door of the freezer was exposed, the cold air escaping. The internal rock melted into water is also the main reason for preventing the stone from flowing. In addition, the ice compartment is clinging to the snow, when the cabinet is in an interrupt mode, the melted snow layer also creates water spilling out. Not only that, the cooling capacity of the freezer compartment is reduced, not enough temperature to freeze the food, causing the stone to melt. And there is one more problem that you arrange food in an unreasonable freezer, which leads to thawing and watering in food.



How to fix:

Check the heating system of the refrigerator, adjust the appropriate heat level to ensure the best preservation process. Arrange food appropriately, don't put too much food in the freezer. Close the cabinet door after each opening. If you still do not lose, you should check the rubber gasket of the refrigerator to avoid the situation of open cabinets, causing loss of heat causing watery phenomenon.

Limit the flow of water in the refrigerator

1. When the refrigerator is watery, it is a sign that you may be using the device improperly, or that the refrigerator is experiencing some internal trouble.
2. Take a closer look at the foods that are being stored inside, then check the water that is flowing from the location in the refrigerator for a reasonable remedy.
3. Regularly clean, clean the refrigerator periodically to help the refrigerator work better.
4. When storing foods such as vegetables, tubers, fruits in the refrigerator, it should be covered with food wrap or use a vacuum machine to drain all the water, keep food fresh and better preserved.
5. Check to see if the refrigerator door is open, check the snuff grip of the refrigerator rubber gasket.

>>> References: "How to clean the refrigerator"

Hopefully with the above useful information, you will have experience using safer and more durable refrigerators. Thank you for your interest and following our article!

You finished reading the article "**5 main reasons why the refrigerator is watery - How to fix it**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.