

Air conditioner error code, Funiki air conditioner and common error handling

The error code of air conditioner, Funiki air conditioner and how to handle some common errors below will help you a lot in repairing.

Air conditioner Funiki works abnormally, along with strange symbols like F1, F2, E4, . appear on the screen? Do not worry! What you need to do now is check the error code, air conditioner, Funiki below to find out the cause and the most accurate way to fix.

content

1. Funiki air conditioner error code
2. How to fix some of the most common error codes and air conditioner Funiki

Funiki air conditioner error code

Funiki air conditioner code

Model

Error name

E01

FC45M, FH45M

Air sensor error 10 Kohm. Air conditioner does not work, the phenomenon of power loss.

E02

FC45D, FH45D

The high temperature protection sensor inside the house is damaged (the compressor does not run). Need to check sensors and gas.

E02

FC, FH45

Only the home fan runs, low pressure valve error, high pressure, phase difference.

E02

FC45M, FH45M

Error sensor staging 10 kohm.

E03

FC45D, FH45D

Error protecting sensor from freezing in the house (block not running). Carefully check the sensor, check the gas.

E03

FC45M, FH45M

Sensor error outdoor 10 Kohm sensor. Can turn off the machine still running normally.

E04

FC45D, FH45D

Gas loss protection error, only indoor unit fan running. Fix by opening and reloading gas.

E05

FC, FH45

Air sensor error, staging sensor error (running 45 minutes, interrupting 10 minutes).

E06

FC, FH45

Staging sensor error (operating 45 minutes, interrupting 10 minutes). Need to check the 10 Kohm probe and plug.

E06

FC45M, FH45M

Incorrect phase, faulty phase protector, high pressure test, low pressure due to cable blocking, excess gas or lack of gas.

E07

FC, FH45

Error of outdoor unit sensor. Fix by checking the 10 Kohm probe and plug, can turn off the detector at the control circuit board.

E09

FC, FH45

Only the indoor unit fan runs, it may be due to out of gas or the wrong indoor unit sensor.

E1

FC, FH24M

Air sensor error.

E2

FC24M, FH24M, FC27M, FH27M

Staging sensor error.

E2

FC45D, FH45D

Sensor error of indoor unit.

E4

Fan cage error is not running due to being stuck or broken.

E5

Air sensor is broken or touched; The plug is loose or broken.

E5

FC24, FH24, FC27, FH27

The sensor is wrong or the system lacks gas.

E5

FC45D, FH45D

Air sensor error (works 45 minutes, interrupts 10 minutes).

E6

Sensor error is broken or short, loose or broken plug.

E6

FC24, FH24, FC27, FH27

Air sensor error (works 45 minutes, interrupts 10 minutes).

E6

FC45D, FH45D

Staging sensor error (operating 45 minutes, interrupting 10 minutes).

E7

FC24, FH24, FC27, FH27

Fault sensor, wiring, jack sensor error (works 45 minutes, interrupts 10 minutes).

E9

Error missing gas; electric pressure; sensor with wrong value.

FC

Reset button is stuck

FF4

FC, FH27G

High temperature protection sensor error; need to check plugs, sensors and gas.

FF7

FC, FH27G

Air sensor error, sensor resistance 5 Kohm.

FF8

FC, FH27G

Staging sensor error, sensor 5 Kohm. Gas and plugs need to be checked.

How to fix some of the most common error codes and air conditioner Funiki

Thus, we have provided you the detailed Funiki air conditioner error codes. Use it to identify the 'disease' that your device is having and have a timely solution.

In the errors in the table above, E4 and E6 are the most common codes.

1. **Air conditioner, air conditioner Funiki error E4:** Cooling fan for indoor unit (cooling fan for indoor unit) does not work or there is no warning signal for the processor. To remedy this situation, you first need to check if the fan is working properly. In case the fan is still operating normally, it is likely that the board is damaged. If the fan is not running, it may be due to the power supply or the indoor unit fan has been damaged.
2. **Air conditioner Funiki error E6 :** This is the sensor of the indoor unit sensor. If the air conditioner Funiki reports E6, you can replace the sensor of the indoor unit and replace the correct value.

Hopefully, our share of **Funiki error codes** and how to fix some common problems will help you a little. Visit META.vn if you need more advice on air conditioning, Funiki air conditioning.

>>> More references:

1. [Air conditioner, LG air conditioner has any error codes? What is the cause?](#)
2. [Midea means the most common air conditioning and air conditioning codes](#)
3. [Learn the most common Mitsubishi air conditioner fault codes](#)
4. [\[Summary\] Causes and ways to fix error codes Air conditioner, Gree air conditioner](#)
5. [Detailed summary of common error and trouble codes in air-conditioners and air conditioners Sharp](#)
6. [Instructions for reading code of air conditioner, Casper air conditioner for quickest repair](#)

You finished reading the article "**Air conditioner error code, Funiki air conditioner and common error handling**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.