

Causes and how to fix laptop microphone not speaking

Causes and how to fix laptop microphone not speaking simply and in detail 2022. Quick fix.

The microphone error in Windows 10 is very annoying for users because we usually only use the microphone when necessary. There are many causes of microphone problems for laptops, in many cases you can fix it yourself at home. In addition, it may also be due to a more difficult problem with the hardware, you will need the help of technicians. Please refer to the article below of TipsMake to find out the cause and how to fix the laptop microphone error that cannot speak!

Reasons why laptop microphone cannot speak

Laptop microphone not working is a common problem. To fix this problem, you first need to find out the cause.



- Some main causes leading to the error of laptop microphone not being able to speak:

- + Due to jack
- + Driver is faulty or outdated
- + Microphone settings on laptop not enabled
- + Sound Troubleshooter

How to fix laptop microphone not speaking

After knowing the reason why the laptop microphone cannot speak, depending on the error, you can apply different solutions.

Check the jack again

- When the laptop microphone does not speak, you need to check the jack between the microphone and the computer. The contact point of the socket and the socket is too loose, causing a poor connection and the microphone cannot speak. You can unplug and plug it in again many times, rotating the jack to get the best contact. Or check the socket again, it may be wrong, causing the microphone to not speak.



Turn on microphone in Windows 10 settings

- The laptop microphone cannot speak, it can also happen because you forgot to reset the operating mode. This leads to the situation of losing microphone sound, not being able to speak. The way to fix this situation is very simple, you just need to reset this mode and you're done.

- How to do:

Step 1:

+ Method 1: Open Start Menu -> Select Settings

+ Method 2: Use the shortcut key combination Win + I

Step 2: Click on Privacy -> Then select **Microphone**

Step 3: In Allow apps to access your microphone -> Enable ON mode

Check and update Driver

- Faulty or outdated drivers are also common causes of laptop microphone not being able to speak. You can check and fix it in the following way.

Step 1 : Select Start Menu or press Win key

Step 2: Search for Device Manager

Step 3: Click on Sound, video and game controllers to expand the sub-items inside.

Step 4: The sound drivers will appear on the screen:

+ Intel(R) Audiodisplay

+ Realtek High Definition Audio

Step 5: Right click on Intel(R) Audiodisplay -> Click Properties

+ If the line The device is working properly appears: it means the driver is working properly

+ If not: go to Step 6

Step 6: Select the Driver tab -> Select Update Driver to install the latest version

Step 7: Repeat Steps 4 - 6 with other sub-items of Sound, video and game controllers -> Restart your computer and check if your laptop microphone can speak.

Check sound settings to fix laptop microphone not speaking


Step 1: Right click on the speaker in the right corner of the screen, on the taskbar -> Select Sound Options

Step 2: On the Recording tab -> Click Microphone -> Select Properties

Step 3: Click on the Levels tab -> Increase the volume for Microphone & Microphone Boosts

Step 4: In the Enhancement tab, select Immediate mode

Step 5: Click OK -> Restart computer



Laptop microphone cannot speak due to disabling Exclusive Mode

- Exclusive Mode is a mode that can exclusively control your sound card. This option may have interfered with some drivers, causing the laptop microphone to not speak.

To fix the problem of laptop microphone not being able to speak due to Exclusive Mode, you need to follow these steps:

Step 1: Right click on the speaker icon on the taskbar -> Select Microphone Properties

Step 2: On the Advanced tab, in the Default Format option -> Turn off the Allow applications to take exclusive control of this device option (In the Exclusive Mode section)

Step 3: Select OK. If the mic still doesn't work, you need to turn the option back on.

Sound error troubleshooter

Step 1: Right click on the speaker icon in the lower right corner of the screen

Step 2: Select Troubleshooter sound problems

Step 3: Audio related errors will be displayed on the computer screen.

Step 4: Click on the Yes - Next - Play - OK options to remove these errors.

Conclude

If the laptop microphone cannot speak, you can simply follow the instructions above at home if the error is mainly due to software, but if it is due to hardware, you need to bring the device to a reputable repair center. For any questions, please contact the hotline: **1900 1903** for the best advice and support. Wish you successful application of the instructions!

You finished reading the article "**Causes and how to fix laptop microphone not speaking**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for

similar articles on tips and guides. Thank you for reading and for following us regularly.
