

Causes of no sound on computer speakers and how to fix it

What are the causes of no sound on computer speakers? And the simplest instructions on how to fix no sound on computer speakers.

What are the causes of no sound on computer speakers? And how to fix it? Let's find out with TipsMake through the following article to understand better!

Why are there no sound on computer speakers?

There are many reasons why computer speakers cannot be heard, but the most common reasons are the following:

- You have not enabled Playback Devices

Maybe you pressed the wrong command during the operation and turned off Playback Devices, causing the laptop to lose sound.



You can check by right-clicking on the speaker icon on the Taskbar, select Playback Devices. The activated speaker will be green.

- Computer speakers have no sound due to hardware failure

After a long time of use, some components may be damaged, causing the computer speaker to have no sound or be unable to hear any sound.

- Software conflicts on the computer

One of the reasons why computer speakers cannot be heard could be due to software conflicts with each other.

- Due to jack, speaker volume is not turned on

If your laptop uses external speakers but the sound is muted or you can't hear anything, it may be because the speaker jack is broken or you plugged it in the wrong jack.



There are also some cases where you forget to turn on the speaker, or the volume is too low. This is also one of the reasons why the computer speaker has no sound.

How to fix computer speakers with no sound

After knowing some of the reasons why your computer speakers are muted and cannot be heard. Here are some solutions you can refer to:

1. Check the volume

- Many times during use, you accidentally turn off the computer sound with commands on the keyboard without you noticing. Therefore, the first thing you should do is check the volume on the computer, check the speaker volume to make sure it is turned on.

How to do: Very simple, to check you click on the speaker icon on the bar. The speaker icon is blue when the sound is turned on.



2. Check the application volume

- Many programs and applications have their own volume controls. So make sure the sound in the program you are using is turned on.

For example, a DVD player will often have its own audio controls or increase the volume in Youtube.


3. Check the connection port to the speaker or headphone

To get sound into headphones or external speakers, you need to plug the jack into the Line-out port. If you can't hear anything from the built-in speakers on your computer, you may have plugged it in the wrong way or the wrong jack. So you need to check the ports and jacks to make sure everything is connected correctly.

- Also if you are connecting HDMI to a monitor with built-in speakers then the computer sound may disappear because the HDMI video card is not the default sound device.

4. Restart Windows

Your computer still has no sound, cannot hear after checking the speaker volume, application volume, then you should try turning off and restarting the computer.



Restarting Windows is one of the ways to fix **the computer speaker** has no sound. Because when restarting the computer, the system will be reset to its original state. Because this can fix the sound loss error caused by the operating system, fix errors caused by software conflicts,.

5. Use Microsoft FixIt Troubleshooters

For computer sound problems, Microsoft has a few solutions:

If you use Windows 7 to fix the problem of computer speakers not working is very simple. First, go to "Start" select "Control Panel" > select "Troubleshooting" > In "Hardware and Sound" select "Troubleshoot audio playback" > In the new window that appears, select [Next] to run the sound repair program.

Above are the ways to fix the problem of computer speakers having no sound, not being able to hear very simply, right? And if you encounter the above situation, please refer to and follow the methods that **TipsMake** has shared above. Guaranteed you will solve the problem quickly and accurately!

You finished reading the article "**Causes of no sound on computer speakers and how to fix it**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.