

# Error self-exiting apps on iPhone causes and fixes

Helps you to troubleshoot an application that is in use suddenly crashed on iPhone and the cause of application exit.

With the habit of using many applications at the same time, surely iPhone users have encountered many cases of suddenly returning to the home screen while texting or playing games, . Let's take a look at the article. Below to learn some causes and how to fix self-exit errors on iPhone !


## 1. Many applications run in the background

We have a habit of opening and using many different applications on the phone and returning to the home screen always, forgetting to turn off the open application.


For example: You are opening a Facebook app or any application but forgot to close the application window, then press the Home button to return to the home screen to open another application. Such applications are called background applications on the phone.

- Remedy: Turn off applications running in the background.


Step 1: Double-click the Home key to open the application running in the background



For iPhone models without the Home key. To do this, swipe up from the bottom of the screen to the center, then release.



Step 2: Swipe up the screen to turn off applications running in the background.



## 2. The device memory is full


Unlike Android phones, iPhone users cannot manually add storage to the device through MicroSD cards. Therefore, after a period of use, it will inevitably be that the memory is full, making the processing worse.

- Remedy: Delete unnecessary applications.


Step 1: Go to Settings > Select General.



Step 2: Go to iPhone Storage> Select Apps to delete.



Step 3: Select Delete app> Confirm Delete App.



### 3. Conflicts between applications

When using Cydia's top-of-the-line apps, incompatibilities occur very often. As a result, some applications that you are accessing will be dropped and there are some applications that do not work resulting in sudden exit.



- How to fix

To be sure, you should only use apps on the App Store. If when you use the app and exit suddenly, uninstall the suspicious apps and re-download it on the App Store.

### 4. Error the iOS version in use

If you have tried to check and fix the above errors but your iPhone still has the error of self-exiting the application, it is possible that the iOS version you are using is faulty or outdated, resulting in slow processing

speed.


- How to fix: Updating iOS to a new version is absolutely essential for peace of mind when using the device, as well as minimizing the error of sudden application exit on iPhone.

Step 1: Go to Settings> Select General.



?

Step 2: Select Update Software> Tap Download and install and wait for your phone to update the software.



Thus, the article has mentioned and instructed a number of ways to fix unexpected self-exiting errors on iPhone. Hope this article has brought useful and complete information for you.

Good luck.

You finished reading the article "**Error self-exiting apps on iPhone causes and fixes**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.