

Extremely effective way to fix the error of laptop not being able to access the main screen

The error of not being able to access the laptop's main screen is a common problem that many users encounter. This article will tell you some ways to fix the error of your laptop not being able to access the main desktop screen.

There are many reasons why a laptop cannot access the main screen. Some cases you can easily fix yourself at home. Below is a way to fix the error of your laptop not being able to access the home screen that you can do.

Turn off and restart the laptop

One of the simplest ways to fix the error of not being able to access the laptop's main screen is to turn off the computer and restart it. Sometimes this can resolve software problems but does not require complex intervention.

To do this, hold down the power button on the laptop until it turns off completely. Then, press the power button again to restart the device. This is a simple and quick fix when you encounter this problem.



Uninstall installed software before the device crashes

Uninstalling the installed software is also a solution to recover a laptop that cannot access the main screen. However, this needs to be done properly to avoid damaging the system. To remove installed software before the computer crashes, do the following:

Step 1: First, click on the search box on your computer and enter the command "Control Panel". Then, click 'Control Panel'. Next, click on the "Programs" section.

Step 2: Here, select "Programs and Features". At this point, the screen will display a list of software on your laptop. To remove a software, right-click on it and select "Uninstall".

After clicking 'Uninstall', click confirm and wait for the uninstallation process to complete. This process will help you fix the problem of not being able to access the home screen on your laptop.

Turn off Windows Update

There are some cases when your device is too old and automatically updates to the latest version. This may cause the laptop to not be able to access the home screen. However, you can resolve this issue by turning off automatic updates.

Step 1: First, access Settings by pressing the Windows + I key combination. And then select Windows Update.

Step 2: Next, select Update & Security and click Advanced options. Then, select Pause Updates to turn off Windows Update. Finally, you choose the time to turn off Windows Update and click Save to save the changes.

Turn off applications that start at the same time as the computer

Having many applications started with the laptop can cause the computer to not be able to access the main screen. To solve this problem and speed up your device's startup, you can turn off some applications. This will help limit screen refresh lag.

Step 1: First, press the key combination Ctrl + Shift + Esc or right-click on the taskbar. Next, open Task Manager.

Step 2: Select Startup apps. Here, you will see a list of applications that can run with your computer when it starts.

Step 3: At this point, turn off unnecessary applications by clicking the On bar to switch to Off.

Remove viruses regularly

To protect your data and laptop from security threats, regular laptop virus removal is necessary. You can use a common method like using Windows Defender. This is free virus software built into the Windows operating system. In addition, you can also use third-party anti-virus software such as Avast, Avira, Kaspersky,.

Delete unnecessary files

Downloaded software, images or files of unknown origin are also the cause of problems that prevent the laptop from accessing the main screen. In addition, storing too many junk files on the hard drive also slows down the computer's performance. To solve this problem, you should regularly check and delete unnecessary files. This helps the computer boot faster and operate smoother.

Delete files in the trash

Once you have deleted unnecessary files from your computer, the next step is to delete them from the trash. This helps ensure data is completely removed. Normally, after you delete a file from your computer's root folder, it will be moved to the trash. These files are retained for a certain period of time before being completely deleted from the drive.

Above are some ways to fix the error of laptop not being able to access the main screen. In addition, you can also apply the above tips to effectively prevent your laptop from being able to access the desktop screen.

You finished reading the article "**Extremely effective way to fix the error of laptop not being able to access the main screen**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.