

Fix common errors on iPhone 6S

Although the latest phone from Apple, iPhone 6S also cannot avoid the common errors such as the fast running out of battery, the pressure-sensitive touch screen is not running or the device is too hot. Below, we would like to show you how to fix the above errors.

Although the latest phone from Apple, iPhone 6S also cannot avoid the common errors such as the fast running out of battery, the pressure-sensitive touch screen is not running or the device is too hot. Below, we would like to show you how to fix the above errors.

Increase battery life

This is a fairly familiar problem on Apple phones and iPhone 6s not exception. According to BGR, short battery life, slow charging speed can be considered the worst point on this smartphone. Although Apple has made improvements to help the processor chip on iPhone 6s consume less power, optimize iOS 9, but the new model has lower battery capacity than iPhone 6.

To fix this, users should check which application causes the most battery drain. By going to **Settings > Battery** and looking to the **Battery Usage** section, you will be listed its software and energy consumption. Remove unnecessary applications or turn them off.



In addition, the battery life on the iPhone may last by turning off the background application refresh process. Go to **Settings > General > Background App Refresh** and switch to **Off** status or just let the software really needed.

A new feature on iOS 9 helps improve battery life is **Low Power Mode** , activated by going to **Settings > Battery** . At this time, the battery icon will turn yellow and display the remaining battery. However, iPhone 6s will lower the processing speed, turn off some features to extend the time of use, so users can see the machine running slower.

Power failure turned off randomly


Many customers complained about this error on Apple's support page and according to a survey of MacRumors with 1,000 members, about half of them had an iPhone 6s problem at random power off. To turn on the phone, users cannot press the power button in the normal way but must simultaneously hold down both the power key and the Home button for 10 seconds to restart iPhone.



Some experts say that the problem of random shutdown on iPhone 6s comes from the problem of iOS 9 but Apple has not yet released an update. The temporary fix is ??to restore the settings. To do so, go to **Settings > General > Reset > Reset All Settings** . If this is not possible, try the new iPhone installation option or run a completely new firmware version.

The pressure-sensitive screen does not run

Touch screen power is one of the major improvements on iPhone 6s compared to previous products. However, this feature sometimes does not work and receives many complaints from customers. According to BGR, the cause comes from the hardware inside the device, so the only remedy is to bring it to an Apple service center.



However, before that, users should make sure that your iPhone 6s has 3D Touch enabled. Check it by going to **Settings > General > Accessibility > 3D Touch** and making sure it is not disabled. Then you go to the main screen and then emphasize on some icons like Phone, Photo . to see if the device has a submenu.

Machine is too hot

Many high-end smartphones have a hot error and Apple iPhone 6s are also called for this issue. On the Redit forum, some customers said they received a message that the phone was too hot, so the device did not support activating the LED flash when entering the camera.



The cause of the problem may stem from hardware and software design. However, before that users can check the applications installed on iPhone 6s by going to **Settings > Battery** . If there is any software in the Battery Usage list accounting for 35-40% but you rarely use it, turn off the application in the background to run underground or remove.

If there are no battery abnormalities, go to **Settings > General > Reset** and select **Reset All Settings** to return the device to the default settings. The above ways do not help improve the situation, try rerun the software for iPhone 6s with the latest version.

Home key is overheated

According to reports of 9to5Mac, many iPhone 6s users are complaining about the status of fingerprint sensor having too hot condition. The issue is also mentioned in some question and answer topics on Apple's support page.



Similarly the case with 3D Touch does not work, the Home key on iPhone 6s too hot may stem from a hardware problem. The best solution is for the user to bring it to an Apple store or customer care center.

1. Lock iPhone remotely when you lose it
2. How to set a password for iPhone?
3. Some ways to use iPhone battery effectively

You finished reading the article "**Fix common errors on iPhone 6S**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.