

Fix touchpad error on Acer ES1 laptop not working

Touchpad not working error sometimes occurs with Laptop lines. On Acer ES1 Laptop and many other laptop models, when the Touchpad not working error occurs, you need to fix the Touchpad error on Acer ES1 laptop with the following methods.

Normally, Laptop users who use wired mice often find ways to turn off the Touchpad to operate more easily on the keyboard. Because, you need to turn off the laptop mouse so that when typing, your hand won't touch it, causing the letters to jump around. But if the Touchpad doesn't work, and you don't turn off the Touchpad, it's a big problem. For Acer ES1 laptop not working, you need to fix Touchpad error on Acer ES1 laptop in the ways we wrote in this article .

1. Check the function button


This function button is located above the touchpad, allowing on/off the touch mouse.

2. Disable Driver Touchpad

Step 1: Go to **Device Manager** on your computer, select **Mice and Other Pointing Devices**.



Step 2: Right-click **Synaptics PS/2 Port TouchPad** and select **Disable**



3. Use the Fn function key

Combine Fn with 1 in the key sequence from F1 -> F12

- **Fn + F7** for Acer Aspire Laptop



4. Plug in the mouse wire.

On some Acer Laptops, when you attach the mouse to the USB port or PS/2 port, the machine will automatically recognize and turn off the Touchpad.



5. *Hardware error.*

- Check the mouse pad to see if it is touched or not.
- Check contact circuit.
- Replace the management I/O chip.
- Replace mouse pad.



With the above methods, try them one by one if the Touchpad does not work.

To limit Touchpad use leading to keyboard and mouse damage on Acer Laptops, users should be familiar with keyboard shortcuts on the computer. Just memorize the keyboard shortcuts on the computer and your work on the computer will be much faster. Using computer shortcuts also saves more time than the Touchpad's crawling speed.

The obsession with laptop users is probably spilling water on the laptop keyboard. Because the laptop keyboard

is designed seamlessly with the laptop, when water is spilled on the laptop keyboard, it will easily damage the device. You should read the article **on how to fix the problem of laptop keyboard getting wet** so that if you encounter this situation, you will know how to handle it quickly and limit damage.

You finished reading the article "**Fix touchpad error on Acer ES1 laptop not working**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.