


# Fix 'Unable to Join Network Failure (error -3)' error on iPhone

Unable to Join Network Failure (error -3) error message appears on iPhone when Wi-Fi network is not connected. In fact, the reasons for this are the same as for computers that are not connected to a home network or wireless hotspot.

The "Unable to Join Network Failure (error -3)" error message appears on the iPhone when the Wi-Fi network is not connected. In fact, the reasons for this are the same as for computers that are not connected to a home network or wireless hotspot. To resolve these issues, do the following:

1. Check the SSID name settings on the iPhone to make sure it matches the Wi-Fi hotspot. SSID is quite sensitive case.
2. Check the security configuration (WEP or WPA parameters) on iPhone to make sure the values ?? (encryption key or password) match the access point. The encryption keys are not case sensitive, but the password is.
3. If both steps do not fix the problem, fix the security settings on the Wi-Fi hotspot. Contact the access point administrator for further assistance if needed.



See more:

1. How to fix iCloud error requires login on iPhone and iPad
2. Application error on iPhone device hangs, frozen
3. How to fix 5 Safari bugs on iPhone

You finished reading the article "**Fix 'Unable to Join Network Failure (error -3)' error on iPhone**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.

