

How to adjust the fast charging feature on Samsung

Fast charging on high-end Samsung devices will shorten charging time more than usual time.

Samsung now offers more fast-charging features or Samsung Adaptive Fast Charge for high-end smartphones. With this feature, the device's charging time will be reduced compared to other devices.

With most current devices to fully charge the battery you will need to wait more than 2 steps. But if you use the fast charging feature, the charging time only takes more than 1 hour and 30 minutes only. It is quite convenient for users to shorten charging time. However, the fast charging feature currently only applies to some high-end Samsung series like Samsung Galaxy S7, Samsung Galaxy A7 2017, Samsung Galaxy S8, Samsung Galaxy S8 Plus. Some previous Samsung series also support this feature such as Samsung Galaxy Note 4, Galaxy S6, Galaxy S6 Edge, .

And in the process of charging, we can choose to turn on or off fast charging very easily, depending on the needs of each person.

1. Phone does not charge or charge slowly, this is how to handle it
2. How to increase battery life on Samsung Galaxy Note 7?
3. What is wireless charging? Is it faster or slower than charging?

How to turn on / off fast charging on Samsung smartphone

Step 1:

First click on **Settings** on the device and then go to **Device maintenance** . Then, click on **the Pin section** at the bottom of the screen as shown below.

CÀI ĐẶT



Thông báo
Chặn, cho phép, ưu tiên

Màn hình
Độ sáng, Bộ lọc ánh sáng xanh, Màn hình chờ

Hình nền và theme
Hình nền, Theme, Biểu tượng

Tính năng nâng cao
Trò chơi, Chế độ Một tay

Bảo trì thiết bị
Pin, Lưu trữ, Bộ nhớ

Ứng dụng
Ứng dụng mặc định, Cấp quyền ứng dụng

Màn hình khóa và bảo mật
Màn hình khóa, Nhận diện khuôn mặt, Vân tay, Mống mắt

Cloud và tài khoản
Samsung Cloud, Sao lưu và khôi phục, Smart Switch


Google
Cài đặt Google

Hỗ trợ
Nhìn, Nghe, Thao tác và tương tác

Quản lý chung
Ngôn ngữ và bàn phím, Thời gian, Đặt lại

Cập nhật phần mềm





Step 2:

Next click on **the 3 dots vertical icon** in the top right corner of the screen. Users click on **Advanced settings** .






Step 3:

In this Advanced Settings interface you will see a number of notifications and battery options. In the **Charger** section there will be 2 options, including Cable Fast charging and Wireless Quick Charge.

Each fast charging option will have different characteristics. Depending on the needs of each person, you can disable quick charging with a cable or fast charging without wires. Squeeze the horizontal bar to the left to

disable quick charging options.



In general, when using the fast charging feature, the device will have to operate more, radiate more heat. If you do not need to charge the battery quickly, it is best to turn off this fast charging feature.

See also: Why is the fully charged phone still running out of battery?

Hope this article is useful to you!

You finished reading the article "**How to adjust the fast charging feature on Samsung**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.