

How to change WiFi password modem HuaWei VNPT like?

In order to change HuaWei VNPT WiFi modem password, we also need to access the modem administration interface like other WiFi networks.

In the previous articles, the Network Administrator showed you how to change the WiFi password of many networks such as VNPT, FPT, Viettel. And in this article, we will guide you to read how to change the WiFi module HuaWei VNPT. Similar to changing password for WiFi of other networks, users also need to access the modem management page to be able to change pass for VNPT WiFi.

Instructions for changing pass WiFi HuaWei VNPT modem

Step 1:


First, you need to check the back of the HueWei WiFi modem and will see 3 necessary information including IP address, WiFi name SSID and default login password for WiFi. Next, on a computer web browser, we will access the modem management page via the IP address behind the modem.

Normally, the IP address to access the Huawei modem management page will be **http://192.168.100.1** .



Step 2:

After successfully accessing, at the new interface you will enter information at the **Username as root** and the **Password box is amine** . Click **Login** to continue.




The image shows the login page for a Huawei HG8045A device. At the top, there is the Huawei logo and the model number 'HG8045A'. Below this, there are two input fields: 'Account:' with the text 'root' and 'Password:' with five dots. A 'Login' button is positioned to the right of the password field. At the bottom, a copyright notice reads 'Copyright © Huawei Technologies Co., Ltd 2009-2014. All rights reserved'.

Step 3:

At the setup interface for WiFi, we click on the **WLAN tab** . Looking down at the interface below, enter your **SSID Name for the WiFi name** . **WPA PresharedKey** enter new password for WiFi .

To make sure you have entered the correct password, you should uncheck the box at Hide to display the entered password.




The image shows the 'WLAN Basic Configuration' page in the Huawei HG8045A web interface. The 'WLAN' tab is selected in the top navigation bar. The page contains a table of WLAN configurations and a detailed configuration section for the selected SSID.

SSID Index	SSID Name	SSID Status	Number of Associated Devices	Broadcast SSID	Security Configuration
1	VF	Enabled	32	Enabled	Configured

SSID Configuration Details

- SSID Name: [] *(1-32 characters)
- Enable SSID:
- Number of Associated Devices: 32 *(1-32)
- Broadcast SSID:
- Enable WMM:
- Authentication Mode: WPA/WPA2 PreSharedKey
- Encryption Mode: TKIP&AES
- WPA PreSharedKey: [] Hide *(8-63 ASCII characters or 64 hexadecimal characters)
- WPA Group Key Regeneration Interval: 3600 *(600-86400s)
- Enable WFS:

After you have finished entering the required information, we scroll down and click on **Apply** to save the information.



The final action is that we will reconnect from the beginning with WiFi. Since you have entered a new name for WiFi, you will not need to delete the history of connecting to the old WiFi before. In case we still leave the WiFi name but only change the WiFi password HueWai VNPT modem, then you must delete the connection with the previous WiFi. Read more article [How to delete Wifi saved on Windows 10 ?](#).

Refer to the following articles:

1. Instructions on how to change FPT WiFi password
1. How to change the TP-Link wifi password?
1. 2 steps to change Linksys wifi password

I wish you all success!

You finished reading the article "**How to change WiFi password modem HuaWei VNPT like?**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.