

# How to delete the Web browser history on Sony Smart TV

Clearing browsing history on smart TVs will help the TV work more smoothly, freeing up special memory to improve security when using the Web browser.

Currently some smart TVs on the market allow users to connect to the Internet and surf the Web like on a computer. You can enjoy the colorful space on the big screen, with sharp images especially when playing speed games.

The access to Internet TV also makes TV become slower to operate, TV memory is also used quite a lot for surfing the Web. So regularly delete the Web browser to be able to free up some of the memory for the TV, ensuring security when using it.

1. **How to connect a laptop to a TV using an HDMI port**
2. **How to connect mouse, keyboard with Smart TV**


In this article, we will show you how to delete the browsing history on a Sony smart TV, using the **Snoy Entertainment Network interface** . In the course of deleting the browser history, the TV must be connected to the network.

## Step 1:

Access the **Web Browser** on the TV and select **Settings** .




Access the Web Browser from the application page



Click Install

## Step 2:

In the **Settings** section, select the **Recent Search information** section.



Recent browsing history on TV


## Step 3:

We can delete the entire browsing history or choose to delete each history on the TV

## Delete each browsing history item

### Step 1:

Access **History display** .




Select Show history

### Step 2:


The TV interface will show recently accessed browsing history. You **select the browsing history to delete** and select **Delete** and **Confirm agree** (click on the **Options** button on the control to display the options menu).



Select the Web browser history you want to delete



Click Options on the control and select Delete




Complete deleting browsing history


## Delete the entire browsing history

How to delete the whole will be much simpler than deleting each browsing history.

In the **Recent Search information** menu, select **Delete history** and confirm **Agree**.



Select Delete history in Recent Search Information



As such, you can delete the entire browsing history or choose to delete each browser you want. Clean up your television regularly to ensure speed and the ability to surf the Web quickly.

### **Refer to the following articles:**

1. How to install and remove applications on Smart Samsung TVs
1. How to scan and kill viruses, malicious codes on Samsung Smart TVs 2015
1. How to choose antivirus applications for Windows and Mac

**I wish you all success!**

You finished reading the article "**How to delete the Web browser history on Sony Smart TV**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.