

# How to fix Mi Band 4 error when the battery is low

How to fix Mi Band 4 error when the battery is low. Because of its large and colored screen, the Mi Band 4 has problems with its battery when first connected and used. In this article, the Software Tips will guide you on how to fix Mi Band 4 error when the battery drops quickly when used.

Mi Band is one of the most successful smart bracelets in Vietnam as well as worldwide markets. With Mi Band 4, it has improved a lot with the full color screen that is bigger than the black and white screen on Mi Band 2 and 3. Because of the large screen and color, Mi Band 4 has a problem. about the Battery when it is first connected and used. In this article, the Software Tips will guide you on how to fix Mi Band 4 error when the battery drops quickly when used.




## Mi Band 4's standard battery life has fixed the problem

After a long time experimenting with the following settings:


1. Turn on all app notifications
2. Brightness set to level 4
3. Do not turn on continuous heart rate monitoring

With the above setting, almost all the features on Mi Band 4 are enabled, the Mi Band 4 will last 20-25 days.



## **Battery Time of Mi Band 4 without fixing the error**

But the Software Trick also encountered the problem is the first time connected. Mi Band 4 drops the battery very quickly, The battery only lasts 3-4 days. Even on our Mi Band 4 device, we dropped 44% within a day. Below Software tips will show you how to fix errors. This is not a serious error, you just need to restart Mi Band to be compatible with the version of Firmware in use.



## How to fix Mi Band 4 with fast battery drain

**Step 1:** You turn on the screen of the Mi Band and select the **More** section (located at the bottom). At **More** you continue scrolling down to select **Settings** .



**Step 2:** The Settings section will have **Reboot** and **Factory Reset mode** . **Reboot** means that restarting the device doesn't work. You choose **Factory Reset** to restart all Firmware available on Mi Band for stability. When choosing there will be notifications you choose "V" to continue.



**Step 3:** After **Factory Reset** is complete, your Mi Band 4 will return to the **Pair First mode (Device connection)** . You use your phone to reconnect Mi Band and you're done.



After connecting, you can rest assured that your Pin Band 4 will be much more buffalo. Good luck!.

You finished reading the article "**How to fix Mi Band 4 error when the battery is low**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.