

How to fix wireless charging errors on iPhone 8, 8 Plus, iPhone X

You own one of the super products like iPhone 8, 8 Plus or iPhone X, but recently you feel uncomfortable when often encountering wireless charging errors? So read the following article right away to learn how to fix wireless charging errors on these devices in the quickest and easiest way.

You own one of the super products like iPhone 8, 8 Plus or iPhone X, but recently you feel uncomfortable when often encountering wireless charging errors? So read the following article right away to learn how to fix wireless charging errors on these devices in the quickest and easiest way.

1. Quick handling of iPhone screen error is not sensitive and poor
2. Quick charging way iPhone X
3. Tips to help you master iPhone X

How to fix iPhone 8, iPhone X wireless charging error

1. Check the wireless charger for iPhone

If unfortunately iPhone 8, iPhone 8 Plus, iPhone X encounter wireless charging errors, you first need to check the wireless charging parts to determine if the charger is the cause of this problem. ? Proceed in the following order:

1. Check if the plug of the wireless charger is stable.
2. Check if the USB port of the charger is firmly connected.
3. If you see the contact port is dusty, use a dry cloth to clean it to make sure the contact port works best.



IPHONE 8, IPHONE X LỖI SẠC KHÔNG DÂY

Note :


- You have to make sure the tubers charge, the cord connected of the wireless charger is firm, not loosely attached.
- You can choose another device that supports wireless charging to check if the charger is broken.

2. Remove the phone case

Despite the protective or decorative effect, in some cases, unqualified phone cases are the cause of the wireless charging of iPhone 8, iPhone 8 Plus, iPhone devices. X. Therefore, to avoid wireless charging errors, you should remove the phone cover, leather case before performing iPhone 8, iPhone 8 Plus, iPhone X.

3. Try turning off the device or restarting

Another way for you to fix the wireless charging error on iPhone 8, iPhone 8 Plus, iPhone X is to power off or restart iPhone device.



Steps to take:

1. Access the setup application (Settings).
2. Select the general setting (General) and select Turn Off (Turn Off).
3. Retry wireless charging again.

Over here TipsMake.com has guided you to three ways to fix iPhone 8, iPhone 8 Plus, iPhone X without receiving wireless charging or charging with this wireless charger. In the case of iPhone 8, iPhone 8 Plus, iPhone X is still unable to perform wireless charging, you should bring the device to service centers to receive advice, as well as the most accurate answer to the problem. this topic.

I wish you all success!

Maybe you are interested:

1. How to prevent iPhone and iPad from automatically connecting to Wi-Fi network
2. How to change WiFi password (Wifi hotspot) on iphone

You finished reading the article "**How to fix wireless charging errors on iPhone 8, 8 Plus, iPhone X**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.
