

How to force the screen to rotate into Landscape Mode on iPhone

Everyone is frustrated because the way the phone handles auto-rotate features at some point. Sometimes, the iPhone may not realize that you have rotated it, making you a less optimized viewing experience.

Everyone is frustrated because the way the phone handles auto-rotate features at some point. Sometimes, the iPhone may not realize that you have rotated it, making you a less optimized viewing experience.

Of course, iOS provides a way to lock your phone at Portrait Mode (vertical mode). It stops rotating the screen uncomfortably when you just lie while using the phone. But what if you want to force the phone to turn to Landscape Mode (landscape mode or landscape mode)? Read the following article to learn how to do this.

How to tie the iPhone screen in Landscape Mode

1. Use AssistiveTouch feature
2. Use the screen rotation control application
3. Another screen rotation solution
4. Use video rotation application
5. Troubleshoot problems with Landscape Mode on iPhone
 1. Check the screen rotation lock feature
 2. Turn on / off the Display Zoom feature
 3. Acceleration sensor is broken

Use AssistiveTouch feature

[< Accessibility](#) AssistiveTouch

AssistiveTouch



AssistiveTouch allows you to use your iPhone if you have difficulty touching the screen or if you require an adaptive accessory.

Customize Top Level Menu... [>](#)


CUSTOM ACTIONS

Single-Tap [Open Menu >](#)Double-Tap [None >](#)Long Press [None >](#)3D Touch [Home >](#)

Custom actions allow you to interact directly with the AssistiveTouch icon without opening the menu.

Idle Opacity [40% >](#)

CUSTOM GESTURES



You can use AssistiveTouch on iOS to rotate the iPhone screen to Landscape Mode, even if you use the device in Portrait Mode. This is the only available way to force the iPhone screen rotation.

To use AssistiveTouch, you first need to activate it in the iPhone's Settings menu:

1. Open the **Settings** application .

2. Go to **General> Accessibility> AssistiveTouch** .
3. Make sure the switch is at the top of the screen in the **On** position .
4. Click 1 of 4 options (**Single Tap, Double Tap, Long Press** or **3D Touch**) and set to **Open Menu**.
5. Return to the iPhone main screen.

You should now see an emerging icon on the screen. Do any action you set to **Open Menu** in the steps above, then go to **Device> Rotate Screen** . You can force left, right or upside down.

If you worry about the icon on the new screen will cause distraction, don't worry. It will fade when not in use. You can touch and drag to move around the screen.

Unfortunately, after the release of iOS 9, Apple removed part of this feature, and your phone will remain fixed in Landscape Mode until the next time you lock the screen. Now, if you tie iOS to Landscape Mode and then move your phone, setting Landscape will be overwritten.

(**Note** : Screen rotation force will not work on applications that do not support Landscape view. Only iPhone 6 Plus, 6S Plus, 7 Plus and 8 Plus can rotate the main screen. Not included function to rotate the main screen on the iPhone X or above, possibly due to the location of the Face ID camera).

Use the screen rotation control application



CydiaCrawler

About Cydia

EasyAppOrientation

Section: [Tweaks](#)
Name: [EasyAppOrientation](#)
Version: 0.0.1
Updated: 2019-03-26
Price: free
Tags: purpose:extension, compatible:ios8, compatible:ios9
Description: Lock the orientation of applications
Dependence: [firmware \(>= 8.0\)](#) [mobilesubstrate](#) [preferenceloader](#) [aptlist](#)
Size: 18994
View in: [Cydia](#)
Download: [.deb](#)

[How to install "EasyAppOrientation"](#)

- Run Cydia App
- Tap the **Manage** tab available at the bottom of the screen
- Select **Sources**
- Tap on **Edit** button on the top right.
- After that you will see the **Add** button appears at the top Left of the screen
- Enter Cydia/APT URL <http://apt.thebigboss.org/repofiles/cydia/>
- Wait
- Tap **Search** button, enter [EasyAppOrientation](#)

Most iPhone users will be familiar with the jailbreak concept. Doing so allows you to get out of Apple's restrictions. You can install the application and make regular edits not available on iOS.

Explaining how to jailbreak iPad / iPhone is beyond the scope of this article. In fact, you should not jailbreak your phone for security reasons. But if you already have a jailbroken phone, you should consider

EasyAppOrientation. This is one of the only valuable screen rotation control applications for iOS.

EasyAppOrientation is no longer available in any repo. Instead, you will need to download the DEB file and install it manually with Filza.

The application allows you to set up screen rotation on an application-by-application basis. For example, you can make your favorite E-reader application open in Landscape Mode and keep Spotify running at Portrait Mode. The four options available on EasyAppOrientation are **Portrait**, **Landscape Right**, **Landscape Left** and **Portrait (Upside Down)** .

Download EasyAppOrientation (Free):

<http://www.cydiacrawler.com/index.php?cat=package&id=com.nrkvv.easyapporientation>

Another screen rotation solution

If EasyAppOrientation does not provide what you need, you can also check videoplayerrotatable. This app will force the iPhone to rotate every time it plays video, meaning there are no annoying little videos in Portrait Mode.

This application is free to use and available in D4ni's Repo. You can access D4ni's Repo by adding <https://repo.d4ni.nl/> to Cydia.

Use video rotation application



CW90° CCW90° CW180° CCW180° FlipV FlipH Exit




00:01

00:19



SAVE VIDEO TO LIBRARY



One of the main reasons people want to rotate the screen on the iPhone is to watch videos in the correct format. Of course, videos are always better in Landscape Mode, but the nature of smartphones makes most people record their videos at Portrait Mode.

Thankfully, some existing applications can rotate videos on iPhone from vertical to horizontal and vice versa. One of the best video recording apps on iOS is Video Rotate + Flip. Video Rotate + Flip can be used for free;

You can delete ads with in-app purchases.

When you have converted your video from vertical to horizontal in the application, Video Rotate + Flip will export a copy to **Camera Roll** on iPhone. You can force video rotation at any length and the application does not leave a watermark.

And finally, because the videos are rotated at the frame level, the output will be compatible with all video players on a Mac or Windows computer.

Download Video Rotate + Flip (Free).

Troubleshoot problems with Landscape Mode on iPhone

Remember, although the above three methods will allow you to change the screen orientation on the iPhone, but theoretically, the phone will adjust itself whenever you rotate the device physically to the desired position.

If not, here are a few troubleshooting tips:

1. Check the screen rotation lock feature

Are you sure that you didn't accidentally activate vertical view lock? You will find this feature in the Control Center. On iPhone 8 and earlier, swipe up from the bottom of the screen to access the Control Center. Instead, from iPhone X onwards, users must swipe down from the top right corner of the screen.

Here, touch the rotate lock icon (looks like a lock with a circular arrow around it) to enable / disable this feature. This screen lock feature will remain the same until you disable it again.

2. Turn on / off the Display Zoom feature

No SIM

14:16

47%

[Settings](#) Display & Brightness

BRIGHTNESS



Night Shift 22:00 to 07:00 >

Auto-Lock 1 Minute >

Raise to Wake

Text Size >

Bold Text

DISPLAY ZOOM

View Standard >

Choose a view for iPhone. Zoomed shows larger controls. Standard shows more content.



As mentioned, owners of iPhone 6 Plus, 6S Plus, 7 Plus or 8 Plus can rotate the main screen. If it does not, the Display Zoom feature may be faulty. To turn off the Display Zoom feature, follow the steps below:

1. **B1** : Open the **Settings** application .
2. **B2** : Go to **Display and Brightness** .
3. **B3** : Scroll down to find **Display Zoom**.

4. **B4** : Go to **View> Standard** .

3. Acceleration sensor is broken

The phone's accelerometer is responsible for identifying users who are holding their device in horizontal or vertical view. Therefore, if your phone does not dial manually, the accelerometer sensor may be damaged. This is entirely possible, if you have eliminated all other causes.

If you suspect this, you will have to bring your device to an Apple warranty store. Contact Apple support (*reference link: <https://support.apple.com/>*) if needed.

The article looked at how to rotate the screen on the iPhone. The solutions that the article mentioned will solve all the problems related to the screen rotation.

To learn more about how to make the most of your iPhone screen, see how to record the screen on iOS for example.

Hope you are succesful.

You finished reading the article "**How to force the screen to rotate into Landscape Mode on iPhone**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.