

How to handle LG, Toshiba, Sharp refrigerators does not cool the lower compartment

The reason and how to handle LG and Toshiba refrigerators, Sharp does not cool the lower compartment is one of the problems that many people are looking for.

The cool, non-cold compartment is one of the common mistakes in LG, Toshiba and Sharp refrigerators. So what is the cause of this situation? How to handle **LG refrigerators, Toshiba, Sharp does not cool the lower compartment**. Today's TipsMake.com article will help you find out more about this issue!

content

1. Causes and ways to fix LG refrigerators are not cold in the lower compartment
 1. LG refrigerator cause not cold compartment cool
 2. How to fix LG refrigerator cooler is not cold
2. Why is the Toshiba refrigerator in the bottom not cold? How to fix
 1. The cause of Toshiba refrigerator is not cold under the compartment
 2. How to handle Toshiba refrigerator to prevent cool
3. What is Sharp refrigerator cause not cold bottom compartment? Solution
 1. The cause of Sharp refrigerator is not cold
 2. Sharp refrigerator repair solution does not cool the lower compartment

Causes and ways to fix LG refrigerators are not cold in the lower compartment

LG refrigerator cause not cold compartment cool

1. Cool door switch is broken
2. The rubber grating system in the cool door is broken causing cold air to escape
3. The refrigerator fan is broken, causing the cold to be unable to cool off
4. The freezer is frozen and the cold air cannot be stopped,
5. Put too much food in the refrigerator. If there is too much food in a cool compartment, the cold air cannot circulate, leading to a situation where the refrigerator is not cold or the cold air is very weak.
6. The temperature adjustment screw has not been properly adjusted.

How to fix LG refrigerator cooler is not cold

In order to handle the LG refrigerator without the lower compartment, you must first determine the exact cause. Here are some repair solutions based on the reasons we mentioned above:

1. Make sure the parts in the refrigerator compartment are always working properly, especially switches, fans and rubber gouting systems around the door. If it is broken, replace it with it, do not try to use the damaged item.
2. If the freezer is frozen (freezing), just press the defrost button or unplug it, open the cupboard door and wait for it to melt.
3. Do not put too much food in the refrigerator compartment. Limit food to cool compartments when it is too hot.
4. Align the cool chamber temperature to the appropriate level. Note, you should not leave the temperature too low because it will cause electricity.
5. Install LG refrigerator in a cool position, at least 5 cm from the wall.



LG refrigerator is not cold and cool

Why is the Toshiba refrigerator in the bottom not cold? How to fix

The cause of Toshiba refrigerator is not cold under the compartment

1. Broken air conditioner fan: This is one of the common causes that makes Toshiba refrigerator cool. We can check the fan status by applying the ear to the air conditioner. If you hear the roar, the fan is still working or it may be broken.
2. The cool door pad (or rubber pad) is broken, making the refrigerator unable to retain heat, consuming a lot of electricity and causing the machine block to fail.
3. The refrigerator has run out of gas (gas is a refrigerant)
4. The ice compartment is frozen, obstructing the cold airflow that prevents the refrigerator cooler
5. Users put too much food inside the cool compartment so the cold air in the cabinet cannot circulate.
6. The switch in the refrigerator compartment is broken
7. The temperature button is adjusted to the minimum level

How to handle Toshiba refrigerator to prevent cool

1. Repair or replace air-conditioner fans, coolers, rubber doors, etc. when they are broken.
2. Melt snow cubes by disconnecting the power and opening the cabinet door.
3. Refuel gas for refrigerator
4. Just to have enough food in the cool compartment, food to cool compartment must be cold.
5. Adjust the temperature to match the environment and the characteristics of the food.
6. Regularly clean and maintain the refrigerator



Toshiba refrigerator coolers are not cold due to broken rubber

What is Sharp refrigerator cause not cold bottom compartment? Solution

The cause of Sharp refrigerator is not cold

Sharp refrigerators cool compartments can not be caused by one of the following causes:

1. The refrigerator's blower does not work so that cold air cannot flow from the indoor unit to the cooler.
2. Wind down or return airway is blocked
3. Because the food inside the refrigerator is too cold
4. Wastewater is blocked
5. The door of the cabinet is exposed due to broken rubber
6. Thermal sensor is broken
7. Sharp's refrigerator is not cold and cool due to lack of gas and gas
8. Because the throttle valve is broken
9. Because the electronic circuit is broken

Sharp refrigerator repair solution does not cool the lower compartment

1. If the downward wind is blocked, you only need to pull out the refrigerator for about 24 hours and then plug it back in
2. When the sewage line is clogged, it is necessary to unplug the electricity and discharge the sewage and re-plug the power source for use.
3. Repair, replace broken parts
4. Add more gas to the fridge
5. Avoid putting too much food in the cupboard.
6. Wait for the food to cool and then refrigerate it.



Sharp refrigerator does not freeze cold because of too much food

Note

1. Refrigerators prevent coolness due to many reasons and the reasons we listed are just one of them.
2. Should seek professional repair centers in case of need to replace, repair parts of the refrigerator.
3. In case of a new replacement, it should be replaced.

Hopefully, through our article, you will understand the causes and **how to handle LG, Toshiba and Sharp refrigerators**. Visit META.vn for advice and order durable, cheap refrigerators.

>>> More references:

1. How much is reasonable to regulate refrigerator temperature?
2. Have you used the refrigerator properly when you first bought it?
3. Why does the refrigerator lose heat and is not cold enough?
4. How to clean the refrigerator properly?
5. This is what causes the refrigerator to vibrate and shout unusually

You finished reading the article "**How to handle LG, Toshiba, Sharp refrigerators does not cool the lower compartment**" edited by the [TipsMake](http://TipsMake.com) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.