

How to increase or decrease laptop screen brightness

Win 11/10/8/7


Depending on each computer, the way to increase, decrease, and adjust the brightness of the laptop screen will be different. However, if you apply the following method, most of you will be able to adjust the screen brightness of many computers.

Adjusting the screen brightness helps protect your eyes and prolongs battery life when not plugged in. Increase the brightness when it's bright and decrease it when it's dark, ensuring eye comfort. For laptops, the brightness should be set at around 90%, and for desktop screens it's 80-85%.


1. Increase or decrease screen brightness on Windows 11/10 (Update)

One of the simplest ways to adjust the brightness that Windows 10 users can do is the Display mode in Windows 10. This mode not only allows users to fine-tune the screen brightness but also allows the display mode to be as soothing to the user's eyes as possible.


Step 1: To increase or decrease the brightness, first open **the Start Menu** , type **Display** and access the **Change Display Settings** section as shown in the image below.




Step 2: We will see the **Change brightness** section right after that, this is the section that allows increasing or decreasing the brightness and below it is **Night Light**, the section that displays the eye protection mode.




Step 3: The screen brightness will **increase or decrease depending on the level from 1 to 100** , the photo in the picture can hardly display the changing colors. In addition, you can activate Night light and set it in the Night light settings section.



Step 4: In **Night Light Settings**, we can always activate this eye protection mode and adjust the color from **yellow -> white** (default) according to the user's wishes as long as you can still work with that screen.



Step 5: Below, we can activate Schedule to be able to schedule the Nigh Light mode screen more proactively, if according to the default time of Windows 10, it will be after **6:41 pm to 5:17 am** the next morning.



2. Increase or decrease the brightness of HP Dell Asus Lelovo Vaio laptop

Except for old laptops, most devices today have a system of keys to increase and decrease screen brightness and adjust laptop screen brightness in particular. However, each manufacturer has different standards for setting shortcut keys to adjust screen brightness, even the same models do not necessarily have the same keys to increase and decrease screen brightness.

For example: Increase the brightness of Dell, Asus laptop screen, adjust the brightness of PC screen., you can use the key combination. HP usually specifies the key combination **Fn + F2/F3** to increase or decrease the brightness of laptop screen, however, some other manufacturers specify the key combination to increase or decrease laptop brightness as Fn + F4/F5 or Fn + F5/F6, etc.



Increase or decrease brightness laptop hp dell vaio

That is the most common and popular way to increase or decrease the brightness of HP Dell Vaio laptops running Windows 7, 8, 8.1, 10. In addition, users can apply some of the following methods introduced by TipsMake to increase or decrease the screen brightness of HP DELL, VAIO, ASUS laptops,.

Method 1: Increase or decrease screen brightness using Mobility Center

On Win 7, 8, 8.1 and Win 10, press **Windows + X** and click **Mobility Center**.

Programs and Features

Mobility Center

Power Options

Event Viewer

System

Device Manager

Network Connections

Disk Management

Computer Management

Command Prompt

Command Prompt (Admin)

Task Manager

Control Panel

File Explorer

Search

Run

Shut down or sign out




Desktop




Method 2 : Increase or decrease screen brightness using Windows Mobility Center

In the System Tray, find the battery icon and right-click on it, then select **Windows Mobility Center**.



Method 3 : Use commands and shortcuts to increase or decrease screen brightness

Use DOS command with **Windows + R** , then run **mbctr** command




All 3 methods above will give you the computer screen brightness adjustment interface as below. You just need to drag and drop the **Display brightness** bar to increase or decrease the laptop brightness as desired. If you do not need to use it outdoors, it is best to reduce the laptop screen brightness to save battery.




Method 4: Adjust the brightness of the laptop screen by Adjust screen brightness

With this method of increasing or decreasing laptop screen brightness using **Adjust screen brightness** , we can customize the brightness of the screen when the laptop is charging and not charging.


Adjust, increase or decrease the brightness of the HP Dell Vaio laptop screen using the **Adjust screen brightness** function . Right-click on the battery icon in the system tray and select **Adjust** screen brightness.



Right-click on the battery icon and select **Adjust screen brightness** .



Select **Change plan settings** to change battery settings and adjust screen brightness of dell hp vaio laptop.



Next, select **Change plan settings** and adjust the brightness of the hp dell vaio laptop screen in two modes: On battery and Plugged In in the **Adjust plan brightness** section . Click **Save changes** to save all settings to increase or decrease the laptop brightness.

Method 5: Adjust screen brightness using Notification function

This method of increasing or decreasing screen brightness **only applies to Windows 10**.



Click on the **Action Center** icon located in the bottom right corner of the screen and click on the sun icon to adjust the screen brightness. By default, there will be levels from 25, 50, 75 and 100% for you to adjust the screen brightness.


Method 6: Adjust laptop screen brightness using F.lux software

F.lux is an application that adjusts screen brightness on both computers and laptops. After downloading and installing **F.lux** on the computer, users can easily adjust the brightness of laptop and computer screens in real time during the day, or if they want, users can completely adjust the brightness of the computer screen directly as desired.

Access F.lux **Settings** by opening the application, then double-clicking the icon located in the system tray.



In the main interface of F.lux, you drag and drop the slider icon in **Daylight** to adjust the brightness of the laptop or computer screen based on your needs. Of course, you should not increase or decrease the brightness of the laptop too much, which will make it difficult for your eyes to adjust.



So you have finished referring to the instructions for adjusting the brightness of HP Dell Vaio laptops using Win 7/8/10/11. In addition, for more details, TipsMake also guides you on how to **save battery on Windows 7 laptops** , **how to adjust the brightness of Windows 11 computer screens** to help you save in the best way.

On other operating system versions such as Windows 8, 8.1, 10, users have more ways to increase or decrease laptop brightness, so when using it daily, users will easily apply it more smoothly when adjusting the screen brightness as desired. In case you cannot adjust the brightness, you can refer to **how to fix the error of not being able to adjust the laptop screen brightness** here.

You finished reading the article "**How to increase or decrease laptop screen brightness Win 11/10/8/7**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.