

How to reset TP-Link WiFi router

When you forget your WiFi TP Link or WiFi password, you can reset the WiFi Link TP router.

When you proceed to change the WiFi password to a password range that is hard to guess but accidentally forget the WiFi password, for these cases users need to step back to reset the WiFi router. Or if WiFi has trouble, the connection is not stable, you can also apply a way to reset WiFi router.

When you reset the router, the previous settings that you set will erase and restore the original state. Then we can perform custom actions back to WiFi as we like. The following article will show you how to reset the WiFi TP Link modem.

1. Common TP Link modem login addresses
2. 6 steps to block, block website with TP-Link router
3. 8 best wireless Wifi routers 2017

Instructions to reset the WiFi TP Link modem

Method 1: Reset button on WiFi router

First, find the correct reset button on the WiFi router. Usually the TP Link will be located in the range of modem ports. Use a small, sharp tip and press and hold the reset button for about 10 seconds, when the lights are off at the same time, release your hand and wait for the restart.

This method may apply to all other modem manufacturers.




Method 2: Reset on the modem configuration page

Make sure the router is turned on before proceeding to restart. The default login IP address is 192.168.1.1 and 192.168.0.1, or <http://tplinklogin.net/> to login and login, the password is all set to admin.

Step 1:

Access to modem configuration page, TP-Link WiFi router and log in to your account.




Step 2:

Access the path of **System Tools**> **Reboot**> **Reboot** and click **OK** to reset the WiFi Link TP router.



In case you want to delete all settings and reset the TP Link router back to its original state, when you first purchased, click **Factory Defaults> Restore** to restart and reset the router's TP Link.



Thus, after resetting the WiFi router TP Link any error issues, or forget the WiFi password will be solved, the modem will return to the default state. Now you can change your WiFi password if you want.

See more:

1. Summary of the best Wi-Fi Router devices
2. Speed ??up tips for wireless routers
3. Wiffi transmitters, best wifi modems, worth buying for you

I wish you all success!

You finished reading the article "**How to reset TP-Link WiFi router**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.