

How to turn off battery saving mode on Android, Samsung, Xiaomi phones

Battery saving mode on the phone allows us to extend battery life by reducing the visual effects, preventing apps from running in the background. In the following article, TipsMake.com shows you how to enable, disable battery saving mode on Samsung, Xiaomi Android phone models simply and easily.

Battery saving mode on the phone allows us to extend battery life by reducing the visual effects, preventing apps from running in the background. In the following article, TipsMake.com shows you how to enable, disable battery saving mode on Samsung, Xiaomi Android phone models simply and easily.




Cách bật tắt chế độ tiết kiệm pin trên điện thoại Samsung, Xiaomi


1. Turn on / off battery saving mode on Samsung devices

Method 1: Turn on / off battery saving mode on Action Center

Step 1: You swipe the screen from top to bottom to open the action center and continue dragging down to expand the notification center. You then touch the **Power save** button .




Step 2: Click **Apply** to turn on battery saving mode and the green tick icon appears to be successful. To turn off this feature, you do the first step and the power saving mode will automatically turn off.




Method 2: Turn on / off battery saving mode in Settings


Step 1: Go to **Settings => Device maintenance (1) => Battery (2)** .



Step 2: You choose 1 of 2 settings to save battery **Medium** or **Maximum** . We can turn off the Power **Saver** feature by touching the **Disable** button . If your phone only uses basic features like calling, texting, surfing, then you can set the power saving mode to **Maximum** .




Step 3: After setting the Maximum power saving mode, your phone will use the dark theme to reduce battery consumption performance and turn off the motion effects, Always on Display and battery life. Usage can be up to several days.



2. Turn on / off battery saving mode on Xiaomi phones


Method 1: Turn on / off Battery Saving feature in Action Center

Swipe the screen from the bottom to open up the action center and continue swiping down to expand. You then touch the **Power save** button to turn on Power Saving. To turn this off, tap the Power saver button again and you're done.




Method 2: Turn on / off Battery Saving mode in Settings

Step 1: Go to Settings => Battery & performance (1) => Optimize battery (2) .



Step 2: To enable **Power save** , you tricked switch **Battery Saving** to enable is completed. To turn off this feature, you turn the switch from **On => Off** is done.



The battery saver mode on your phone is useful when we are running low on battery power and there is no charging in hand. However, this feature will affect the experience on the device such as lag when playing games, dark screen, not receiving Facebook notifications . You should use this feature properly and should not be abused. So much for bringing you the best mobile phone experience! Good luck!

You finished reading the article "**How to turn off battery saving mode on Android, Samsung, Xiaomi phones**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.