

# How to upgrade SIM pairing version 1 to version 2 does not need to buy a new paired SIM

The last SIM transplant version 2 was officially available for use on iPhone Lock with the ability to fix full errors for the device. We can upgrade SIM pairing version 1 to version 2 without buying a new paired SIM.

With the iPhone Lock series, SIM cards become "divine" when you can use as an international iPhone version with extremely cheap prices, without having to contact the network to buy the code to unlock the device at a cost. very high.

And after the previous SIM period was fixed by Apple, the SIM version 2 version has officially returned to iPhone Lock users. According to the announcement, this SIM card will also fix the entire bug on iPhone Lock as SIM version version 1 version before. In addition, it can also be used for iPhone Lock of Sprint operator.

However, the current SIM transplant version 2 is available in limited quantities and relatively high prices. So if users need to use SIM version 2 version, you can upgrade version 1 to version 2 without buying a new paired SIM.

1. How to accurately check the lock or international version for iPhone
2. How to check which iPhone Lock belongs to the network
3. Instructions to turn off audio capture on iPhone Lock iOS 10

## Instructions for updating SIM version version 1 to version 2

Simulated SIM version 2 will also use the ICCID code (Integrates Circuit Card Identifier), the SIM number that iPhone device used to "fool" Apple similar to SIM version version 1. The ICCID series consists of 19 or 20 characters but on verison 2 we will have to change this ICCID number sequence.

We will have to change the ICCID of the sim card you are using to use this ICCID number: 89860600502000180722.



## 1. For GPP Pro 2 paired SIM on iPhone:

You go to **Settings> Phone> SIM application> Edit ICCID** (2nd line from bottom up).

Enter **the new ICCID code 89860600502000180722** and click Submit. Then restart the device to finish.

If you previously selected # mode, press \* 5005 \* 7672 \* 00 # select any network and select ICCID Mode.

## 2. For Heicard SIM pairing (v3.1) on iPhone:

We need to upgrade to v3.1 to be able to proceed.

First, press \* 5005 \* 7672 \* 00 #> Reset Settingd, then exit and continue.

Press \* 5005 \* 7672 \* 88 # and **enter the new ICCID code 89860600502000180722** . Finally restarted the phone.

Some other SIM lines can be matched if you have ICCID correction feature, you can follow the above instructions.

So you can upgrade SIM transplant version 1 to version 2 without having to buy a new paired SIM, by changing the ICCID code range. Before waiting for more SIM shipments to version 2 and the price is stable, not too high, we can also use the above method.

I wish you all success!

You finished reading the article "**How to upgrade SIM pairing version 1 to version 2 does not need to buy a new paired SIM**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.