

How to use the touchless scrolling feature on Oppo.

On some recently released Oppo phone models, users will experience a new feature called Air Scroll, a touchless gesture function.

On some recently released Oppo phone models such as the Reno, F series, and flagship Find X series, users can experience a new feature called Air Scroll, a touchless gesture function. This feature allows you to control scrolling in supported apps and manage calls by waving your hand near the camera without touching the screen. Below is a guide on how to use the touchless scrolling feature on Oppo phones.

Instructions on using the touchless scrolling feature on Oppo phones.

Step 1:

Users access **Settings** on their Android phone and then tap on **Accessibility & Convenience** .

Next, users select **the Gestures & Motions option** to adjust the gestures and movements for their phone.

9:44

32.0 5G Wi-Fi 88


Settings

 Location >

 Digital Wellbeing & parental controls >

 Apps >

 Battery >

 Accessibility & convenience >

 AI >

 System & update >

 About device >

 Users & accounts >

 Google >

 Help & feedback >



12:11

9:27 50% VoWiFi 4G LTE 5G

← Accessibility & convenience

Screenshot >

Screen recording >

Gestures & motions >

Drag & drop
Touch and hold images or text in apps, then drag them to desired locations for more actions. >

Assistive Ball >

Quick Launch
Access frequently used functions while unlocking your device. >

Modes

Zen Space
A flexible app that helps you stay focused. >

Kids mode
Digital Wellbeing starts early. >

Outdoor mode
Get faster internet, precise location tracking and smoother app performance. >



Step 2:

On the new interface, users select the **Air Gestures option** to adjust touchless scrolling gestures on their Oppo phone.

12:11

0.42 5G LTE 84

← Gestures & motions

Touch and hold with 3 fingers to
take screenshot



Take a partial or scrolling screenshot.

Turn on/off torch with volume
button



When the screen is off, press and hold
the Volume Down button to turn the
torch on or off. This function is not
available during media playback.

Air gestures

Control your phone with hand gestures
without touching the screen.



Motions

Raise to wake



Lift to ear to answer calls



Auto switch to receiver

Automatically switch to the receiver
when you lift your phone to your ear.



Flip to mute incoming calls




Shake to launch

None >




Step 3:

The user then taps on **the Air Call Control option and activates Air Call Control** as shown in the image.



Continue to **enable Air Scroll** for the Facebook, Instagram, and YouTube apps.



If you have Air Scroll enabled, open a supported app such as YouTube, Facebook, or Instagram. Then, hold your finger 20-40 cm away from the screen until the hand icon appears, and then swipe up or down to scroll.

If you have Air Call Control enabled, whenever you receive a call, simply hold your palm (open or closed, depending on the model/settings) in front of the camera (20-40 cm away) and wave your hand to answer or mute the call without touching the screen.

You finished reading the article "**How to use the touchless scrolling feature on Oppo.**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.