

# Instruction for using Toshiba air conditioner controller


To use Toshiba air conditioner, firstly you need to use the right Toshiba air conditioner controller with different symbols and buttons.

Toshiba air conditioner brand has launched many different types of products with more modern and more advanced features. Other basic features are similar in the Toshiba air conditioners. And to understand the basic and new features on Toshiba air conditioners, we need to understand the buttons and icons on the Toshiba air conditioner controller. The following article will guide readers to understand the buttons on the Toshiba air conditioner controller.

## 1. Meaning of buttons on Toshiba air conditioner controller

1. Preset: Save the settings for later use.
2. Off / on: Air switch on / off.
3. Swing: Change the direction of the wind automatically and press again to stop.
4. Temp: Increase / decrease the temperature.
5. Mode: Switch modes, there are 3 operating modes: cooling, heating and fan.
6. Fix: Move the flap up and down as you like.
7. One-Touch: Full automatic operation function with just one touch.
8. Power-Sel: Power saving mode button.
9. Fan: Adjust the fan speed button.
10. Quite: Quiet operating mode.
11. Timer: Timer on / off.
12. Comfort Sleep: Sleep operation mode.
13. Hi-Power: High power button.
14. CLR: Delete button.

- 15. Set: Installation button.
- 16. Check: Test button.
- 17. Clock: Time adjustment button.
- 18. Filter: Button reset filter, filter needs cleaning.
- 19. Reset: Reset button.



## 2. User manual for Toshiba air conditioner controller


### Cooling / heating / fan function

Step 1: Press Mode and select cooling, heating, or fan function.

Step 2: Click Temp to set the temperature as you desire.

Step 3: Click Fan, select Auto, Low, Low +, Med, Med +, or High.

To adjust the cooling function, adjust the minimum temperature to 17 ° C. If you select fan only mode, the machine will not have temperature adjustment index. For heating the maximum temperature will be 30 ° C.



## Change the direction of the wind blowing

Press the Fix button in the downward direction of the arrow to move the flap fan downward, creating an instant rapid cooling effect, this function should be used when starting the machine and needs quick cooling.

When the cold has reached the required level, want to switch to cool mode, press the Fix button in the direction of the up arrow to activate, the cool air will spread evenly throughout the room to create the most comfortable feeling and help users have a cold feeling.

Note: Do not use your hands to flap the flaps because the external force may cause damage to the device or danger to users.

Swing mode will help you do that, press the Swing button to activate the mode and press it again to stop.



### **Power saving mode on Toshiba air conditioners**

Press the Power-Sel button to activate this mode. The machine will limit and control the amount of power consumed to bring the best energy saving effect to users.

### **One-touch installation on Toshiba air conditioners**

Clicking on One Touch will launch the optimum temperature & airflow to bring the coolest, most comfortable atmosphere to the user.

### **Timer mode turn on / off Toshiba air conditioner**

In the Timer section, press the arrow up and down the ON area to select the time. Next, press SET to confirm the setting. To cancel timer setting press CLR button.

Turn off the timer we press the arrow up and down the OFF area and do the same as the timer setting mode on.

Note: When the air conditioner is operating we are only allowed to set one of the two timer modes off or timer on. However, with the daily timer, users can set both ON and OFF and will be activated daily.



## **Sleep operation mode**

The Comfort Sleep function automatically controls the airflow and automatically switches off. Press the Comfort Sleep button, and then select the Off time, respectively, 1, 3, 5 or 9 hours, depending on usage.



## Preset mode on Toshiba air conditioner

This mode will save the function for quick boot later. Select the mode you want to save and then press the Preset button for 3 seconds to remember the settings. Then, on the control screen, the "P" mark will be displayed. Click Preset to start the preset function operation.

You finished reading the article "**Instruction for using Toshiba air conditioner controller**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.