


# Instructions for changing Viettel WiFi modem password

The operation of changing Viettel WiFi password is essential, to be able to secure personal WiFi, as well as to ensure the Internet connection speed is stable.

Maybe someday, you will find that there are many neighbors around you who are using your home WiFi without the permission of the landlord to allow access. And this greatly affects the speed of Internet connection, when the number of "WiFi temple" users increases. The best way to limit this situation is that we need to change the WiFi password. In the following article, we will guide you how to change Viettel WiFi modem password.

## Step 1:


First we will access the admin page of Viettel WiFi modem. At the website interface, we will enter the IP address **192.168.1.100:8080** . When the interface appears below, enter the **Username** box as **admin** and **Password** as **admin** .



The screenshot shows the 'User Login' interface of a Viettel WiFi modem. The interface is dark-themed with white text. At the top, the title 'User Login' is displayed in a light blue font. Below the title, there are three input fields: 'User', 'Password', and 'Language'. The 'User' field is currently empty, and the 'Password' field is also empty. The 'Language' field is a dropdown menu with 'English' selected. To the right of the 'User' and 'Password' fields are two buttons: 'Login' and 'Reset'. Below the input fields, there is the Viettel logo, which consists of a stylized 'V' in blue and orange, with the word 'VIETTEL' in blue capital letters underneath. Below the logo, the Vietnamese phrase 'Hãy nói theo cách của bạn' is written in a small, light blue font.


## Step 2:

When successful login information, the new interface will appear as shown below. Here, users click on **Basic Settings> Wireless Lan> SSID Setting** , then click **Modify** .




### Step 3:

Next, we enter the **new password** for WiFi in the **Pre Shared Key** section . Enter a **new name for WiFi** at **SSID Name** . This will help users not need to delete the history of WiFi access on the device.



### Step 4:

Then, click **Apply Config** and then click **OK** to save the change. Finally, restart the device to see if WiFi is available for changes to take effect.



Above is how to change the password for Viettel TP Link WiFi, Totolink, Alacatel, optical cable. After resetting the name and the new password for WiFi, your computer will need time to catch WiFi again so please be patient.

Refer to the following articles:

1. Instructions on how to change FPT WiFi password

1. How to change the TP-Link wifi password?

2. 2 steps to change Linksys wifi password

I wish you all success!

You finished reading the article "**Instructions for changing Viettel WiFi modem password**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.