


Instructions on how to fix the error of laptop screen rotating horizontally!

Have you ever encountered the problem of your laptop screen rotating horizontally? Find out the cause and 6 ways to completely fix the problem of your laptop screen rotating horizontally!

The laptop screen rotates horizontally, affecting the user experience, causing eye pain. And when this happens, many people are confused about the cause and how to fix it. Below, TipsMake will share the causes and ways to fix the laptop screen rotated horizontally, super simple and fast!

Why is the laptop screen rotated horizontally?

After a period of using the computer, if the screen is 180° inverted, also known as horizontal rotation, vertical rotation, then you do not need to worry because this is a common error and can be quickly handled at home. The reason why **the laptop screen is rotated horizontally** is due to:



1. User mistakenly pressed the shortcut key combination to rotate the screen
2. After installing games or software on your computer, you change the screen settings.


You can easily fix a **laptop screen that rotates horizontally** in just 3 seconds at home with the following methods!

How to rotate computer screen upside down from Windows settings

Each Windows version of the computer will have a different custom interface, so you can refer to the instructions on how to rotate the computer screen upside down for each Windows version.

How to fix laptop screen rotated horizontally Win 10

Follow these steps to adjust **the laptop screen to landscape orientation** on Win 10:



Step 1: On the Desktop interface, right-click on any empty space and select Display settings.

Step 2: Then go to Settings -> Click Display -> Drag the mouse to Display Orientation in the Scale and layout section on the right interface -> Select the rotation type you want in the options bar:

1. Landscape: rotate the laptop screen to landscape orientation by default.
2. Landscape (flipped): rotate the laptop screen upside down.
3. Portrait: rotate the screen 90° to the left.
4. Portrait (flipped): rotate the screen 90° to the right.


Step 3: Click Keep Changes to save the computer screen rotation when you see fit. Or select Revert/ press Esc to cancel screen rotation.

How to fix Win 7 laptop screen rotated horizontally

To rotate the horizontal computer screen of Win 7, do the following: Right-click and select Graphics Options -> Rotation -> Rotate To Normal to rotate the horizontal computer screen to normal mode.

How to fix Win 8 laptop screen rotated horizontally

To fix the error of **laptop screen rotating horizontally on Win 8/8.1**, right-click on an empty space on the computer screen and select Screen resolution.



In the Orientation section, select the appropriate screen rotation:

1. Landscape: Rotates the computer screen horizontally by default.
2. Portrait: Rotate the screen 90° to the left.
3. Landscape (flipped): Flips the computer screen upside down.
4. Portrait (flipped): Rotate the computer screen 90° to the right.

Rotate laptop screen with AMD graphics

If your computer uses an AMD graphics card, click the Catalyst Control Center option when right-clicking on the desktop.

Next, find the Rotation option, which may be under different sections depending on whether you're running an older or newer version of Catalyst Control Center. In the newer version, the Rotation option is under Common Display Tasks in the left pane.

Rotate screen with Nvidia graphics card

To fix the problem of **laptop screen rotating horizontally** using Nvidia graphics card, you will see the option to launch Nvidia Control Panel when you right-click on the screen, then select this option instead of Screen Resolution. For laptops using Nvidia graphics card, just right-click on the desktop and select the NVIDIA Control Panel option.

In the new window that appears, click on Rotate Display under Display in the left pane. If you see a message saying that you can't rotate the screen when Stereoscopic 3D is enabled, click on the link and uncheck Enable Stereoscopic 3D. Finally, you'll see options to rotate the screen back under Rotate display.

How to fix Windows 7,8,10 laptop screen rotated horizontally with key combination

In addition to rotating the laptop screen horizontally using Windows settings, you can also use the following key combination to quickly fix screen rotation errors:



1. ALT + CTRL + Up Arrow: Rotate the screen to default orientation.
2. ALT + CTRL + Down Arrow: Rotate the screen upside down.
3. ALT + CTRL + Left Arrow: Rotate the screen 90° to the left.
4. ALT + CTRL + Right Arrow: Rotate the screen 90° to the right.

Note:

You need to enable System Hotkeys to rotate the screen this way.

If you are using the screen toolbar is upside down, you can fix it as follows:.

1. Right-click on an empty area of the Taskbar. Then select Taskbar Settings.
1. In the Taskbar menu bar -> drag down to Taskbar location on screen -> Select Bottom in the options bar to return the Taskbar to its original default position.

Conclude:

Hopefully, with the causes and solutions for **the horizontally rotated laptop screen** that TipsMake has shared in the above article, you can quickly fix this screen error. Please refer to the articles on TipsMake regularly for many useful tips in repairing laptops, PCs at home or buy genuine products at reasonable prices at hotline: 19001903!

You finished reading the article "**Instructions on how to fix the error of laptop screen rotating horizontally!**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.