

# Instructions on how to use the dishwasher Bosch SMS25KI00E

Today's article TipsMake.com will show you how to use the dishwasher Bosch SMS25KI00E in the most detailed and easy to understand.

With its luxurious design and smart features, the Bosch SMS25KI00E dishwasher has been the choice of many homes, restaurants and hotels. Today's article TipsMake.com will introduce briefly and **show you how to use the dishwasher Bosch SMS25KI00E** in the most detailed and easy to understand. Let's get started!

## content

1. Learn about the Bosch dishwasher SMS25KI00E
2. Instructions on how to use the dishwasher Bosch SMS25KI00E
  1. How to install
  2. How to add salt, varnishes and detergents
  3. How to put dishes into a Bosch SMS25KI00E dishwasher
  4. How to operate the control panel

## Learn about the Bosch dishwasher SMS25KI00E

Bosch SMS25KI00E is one of the most typical dishwashers of the Bosch brand (Germany). The product possesses luxurious and modern design. Each time, the machine wash up to 14 sets of dishes, very suitable for use in large families, restaurants, hotels .

Some outstanding advantages of SMS25KI00E:

1. **Features Aquasensor:** When operating, the dishwasher can automatically identify the level of clean dishes, pots, pans through the cleanliness of water, thereby helping to save maximum water and electricity.
2. **Allow setting time and quantity of items to be washed:** With Bosch SMS25KI00E, you can easily set the operating hours before 1 to 24 hours. In addition, the machine also has the feature to identify the number of items to be washed to avoid wasting energy.
3. **Smart control panel:** Dishwasher SMS25KI00E is equipped with a smart control panel system with a clear, intuitive, easy-to-use touch screen. In addition, the machine also has lights to add salt, water to ensure dishes are optimally cleaned.
4. **Some other outstanding features:** 2 washing programs on the top half and VarioSpeed help wash dishes faster, cleaner; The drying mode helps kill bacteria and allows you to use dishes immediately after washing.

## Technical data

1. Noise level: 48dB
2. Water consumption: 12 liters
3. Timer: 24 hours
4. Dimensions: Height x Width x Depth (84.5cm x 60cm x 60cm)
5. Product weight: 51kg
6. Power consumption: 1.05kWh / 140 minutes
7. Quantity: 14 European suits
8. Warranty: 24 months



Dishwasher Bosch SMS25KI00E

## Instructions on how to use the dishwasher Bosch SMS25KI00E

### 1. How to install

The Bosch SMS25KI00E is a standalone dishwasher, so you can install it anywhere in the house, just make sure the location is right for your size (bottom area 60cm x 60cm, height 84, 5cm). In addition, you can also remove the top cover of the machine and mount the cabinet with dimensions of about 60cm x 60cm x 81.5cm. Regarding how to connect the power and water lines, you can refer to the manufacturer's detailed instructions. If you can't install it yourself, you can ask a qualified professional.

## 2. How to add salt, varnishes and detergents

After installation is complete, you need to add salt, varnish and detergent to the dishwasher. Salt has the effect of softening water, limiting deposits that clog water pipes. Shadow oil helps polish dishes. Detergents help clean dishes and need to be provided for each machine's operating cycle (each wash).


1. Salt will be placed in the compartment at the bottom of the washing chamber.
2. Gloss and detergent are put in a drawer on the inside of the door.
3. When the salt and oil create a shadow, the indicator light on the display will light.

## 3. How to put dishes into a Bosch SMS25KI00E dishwasher

Bosch Dishwasher SMS25KI00E has 3 stacks: The top truss is used to stack small items such as knives, forks, spoons, chopsticks...; second frame is used to arrange dishes; bottom truss for stacking pots and pans. When placing dishes and other items on the truss, you need to align them in the designed direction, do not place the dishes on top of each other or face the dishes upside down as this will reduce the contact of the water jets. , making it impossible to clean dishes. If you want to have more space to arrange items, you can move the Rackmatic technology tray up and down by about 5cm.

## 4. How to operate the control panel

Bosch SMS25KI00E owns 5 washing programs including intensive wash, automatic wash, economical wash, overnight wash and 1 hour quick wash. In addition, this device also has 2 additional options of accelerating VarioSpeed Plus and Extra Dry enhanced drying.



Control panel of dishwasher SMS25KI00E

### Washing steps with the Bosch SMS25KI00E dishwasher

1. **Step 1:** Press the Power key to operate the device.
2. **Step 2:** When the display lights up, use the knob to select the appropriate washing program.
3. **Step 3:** To activate additional options, press the corresponding option button. To cancel the option, press the button again. The screen will then display the amount of time needed for the wash settings that the user has set.
4. **Step 4:** Press Start to start the machine.

### How to use the timer feature

To activate the DelayTime timer feature, press the time option button before clicking Start. At this point, the display will show a delay of 1 to 24 hours. You just need to turn the knob to select the desired time and then press the Start key, the machine will start operating after the delay time has been set.

### **How to reset the settings**

If you want to adjust the settings after finishing the setup and let the computer boot, you need to press and hold the Start key for about 3 seconds until the screen shows the number of 1: 1. About 1 minute later, the machine will stop all running programs. At this point, you just need to turn off and on the computer with the Power button and then reinstall the program for the computer normally.

Hopefully our guide on how to use the dishwasher Bosch SMS25KI00E will help you. Wish you have the best experience with this device!

### **>>> Maybe you are interested in:**

1. [Experience] Should buy a good dishwasher, cheap?
2. Do dishwashers wash pots and pans?

You finished reading the article "**Instructions on how to use the dishwasher Bosch SMS25KI00E**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.