

Instructions on how to use wifi adapter Tenda A9

Let Quangtrimang.com evaluate and learn how to use the wifi adapter Tenda A9 - one of the most popular products today.

Right from the market launch, Tenda A9 has quickly attracted the attention from users. So is the Tenda A9 inverter good? **How to use the wifi adapter Tenda A9** like? Along TipsMake.com learn through the sharing below you!

content

1. Review of Tenda A9 wifi tuner
2. Instructions on how to use wifi adapter Tenda A9 most standard
 1. How to use the wifi device Tenda A9
 2. Things to note when using wifi Tenda A9

Evaluate the Tenda A9 wifi tuner

Tenda A9 wifi tuner or Tenda A9 amplifier is a product of Tenda - one of the leading brands in the field of manufacturing and supplying wifi transmitters. The product possesses a compact, simple design, including 2 antennae (2 antennas). The main task of Tenda A9 is to expand wifi coverage and improve signal strength.

Most users have positive reviews about Tenda A9 amplifier equipment with outstanding advantages such as:

1. Compact design, convenient.
2. Wide coverage: Equipped with 2 3dBi antennas, Tenda A9 can extend wifi coverage up to more than 200 m², transmitting wifi in many directions. This product is really suitable for large spaces, multi-storey houses.
3. Large transmission speed: Tenda A9 wifi adapter has the largest transmission speed of about 300 Mbs, allowing you to comfortably surf the web, play games or do anything without worrying about network outages or drops.
4. Easy to use, compatible with many standards such as 802.11n, wireless router, wifi DSL.
5. Smart Wifi Signal Strength LED feature helps to select the optimal location to improve coverage efficiency as well as performance.
6. LED system helps users easily control the operation of the device.
7. Cheap price: At prestigious addresses like META.vn, Tenda A9 amplifier is being sold at a price of about 215,000 VND. This is a relatively cheap price, suitable for many users.



Tenda A9 - wifi adapter is currently the most popular

From the above reviews, we can see that the Tenda A9 wifi adapter is really a product to choose. The next section, let's TipsMake.com explore how to use Tenda A9 wifi!

Instructions on how to use wifi adapter Tenda A9 most standard

After learning about the quality, surely what you are interested in next is how to use the A9 wireless wifi adapter, right? In fact, using Tenda A9 is extremely simple. Here are our detailed instructions for you:

How to use the wifi device Tenda A9

Step 1: Power the wifi router

Step 2: Open the phone, go to **Settings (Settings) / Connectivity / Wi-Fi**. At this time, the phone screen will display the surrounding wifi networks. You press to connect to the corresponding Tenda wifi network.

Step 3: After connecting successfully, you access the web browser on the phone and type in the search bar the following address: **192.168.0.254** .

Step 4: At this time on the phone screen will appear wifi networks. Click on the wifi network you want to activate and select **Next** .

Step 5: Reinstall the username and password.

1. Uncheck the 'Set up the extender's Wifi name and password to the name as those of the Base Station'
2. Enter the wifi password you want to click in the first box 'Enter the Wifi password of the Base Station'.
3. Give Tenda A9 a new name for the wifi adapter by entering any name you want into the next box 'Wifi Name of the Extender'.
4. Enter the new password for the wifi enabled device in the 'Wifi Password of the Extender' box
5. Click **Finish** and wait until the screen appears 'Extended Successfully'.

Step 6: Exit the browser and reconnect to the wifi signal from the router by following the steps below:

1. Go to Settings / Connections / Wifi
2. Select the name of the wifi adapter you just changed / Enter a new password to connect.

Step 7: Connect to the wifi network successfully and you can comfortably access the web, watch videos, play games as you like.



How to use wifi device Tenda A9 extremely simple!

Things to note when using wifi Tenda A9

Besides being very clear how to use the wifi adapter Tenda A9, you should also note some of the following issues:

1. The network transmits wifi from Tenda A9 or any other stimulator that is essentially a broadcast network, that is, retrieves the network from the router and then replays it. To ensure safety, we should only use it for entertainment purposes, not payment transactions.
2. Do not install the wifi adapter on your phone that contains important information.
3. Always take precautions and ensure compliance with security principles.

Hopefully our share of the evaluation and **usage of the Tenda A9 wifi adapter** will be really helpful. Good luck!

>>> **See more:**

1. Tips to increase Wifi signal to the highest level
2. How to find out the Wi-Fi password of a relative's house

You finished reading the article "**Instructions on how to use wifi adapter Tenda A9**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.
