


# Instructions to fix Face ID error not working on iPhone

- If the Face ID feature on your iPhone suddenly stops working, don't worry. The following article will show you how to fix the above error extremely simply.

Face ID is a feature built into Apple iPhone X and onwards. And so far this feature has become the standard iPhone unlocking. With Face ID, your iPhone has an extra layer of security to overcome the weaknesses of Touch ID. But sometimes your iPhone has problems with Face ID, do not worry and refer to this article.

First go to Settings (Settings) then select Face ID & Passcode, then enter the iPhone unlock password.



The next step is to move down and turn off the switch next to the Require Attention for Face ID option.

Finally, click the OK button in the security warning dialog box.

9:41



[Settings](#) Face ID & Passcode

ATTENTION

Require Attention for Face ID

TrueDepth camera will provide an additional level of security by verifying that you are looking at iPhone before unlocking. Some sunglasses may block attention detection.

Attention Aware Features

iPhone will check for attention before dimming the display, expanding a notification when locked, or lowering the volume of some alerts.

[Turn Passcode Off](#)

[Change Passcode](#)

Require Passcode Immediately >

Voice Dial

Music Voice Control is always enabled.

ALLOW ACCESS WHEN LOCKED:

Today View

Notification Center

Now, check the face unlock feature on iPhone again to see if Face ID is working properly.

So I have shown you how to fix Face ID error on iPhone with just a few taps. Thank you for referencing the article. Good luck.

You finished reading the article "**Instructions to fix Face ID error not working on iPhone**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.