

iPhone fix tips are disabled

Disabled iPhone error is one of the most common errors of this phone line. The main reason is due to user mistakes when used. So where is the most standard remedy.

According to the tech experts of TipsMake, one of the most common errors in iPhone users is that the iPhone is disabled. The biggest reason is because users accidentally forgot the password and entered it too many times.

Entering the wrong password 7 times in a row will cause your iPhone to enter a temporary lock state. If you enter the wrong number of consecutive 10 times, the iPhone will automatically delete all data in the machine and fall into a disabled state. However, when encountering this error, users should not be too worried because there are many quick and easy ways to fix it.



Use the utility on iTunes

Technology experts believe that when the iPhone is disabled, using the utility on iTunes is considered the most effective way. For each case, users can follow these ways:

If your iPhone is not connected to your computer and sync iTunes every time, you need to connect your iPhone to your computer via a USB cable and turn off the phone power.

On the computer, start iTunes, the computer screen will now display that the iPhone is in disabled mode, so you need to press and hold the power button and the Home button at the same time for a few seconds. Then release the power button and hold the Home button to return it to DFU mode and restore your iPhone. Wait until the iTunes notification screen has connected to the iPhone and release the Home button.

After successfully putting the iPhone into DFU mode, the computer screen will display the text 'iTunes has detected an iPhone in recovery mode that needs to restore this iPhone before it can be used with iTunes', need to click OK to continue.

Where iPhone connected to the computer regularly backup and sync iTunes. Firstly, users need to connect their iPhone to the computer via the iTunes software by clicking the Back Up Now button to have the computer backup all the information contained in the iPhone. When the Back Up process is complete, select Restore Backup and navigate to the nearest data backup. Then, just wait until the Restore process is finished, you can use the iPhone without the password.

Use iCloud when your phone has Find my iPhone turned on

Users should note that this method can only be used successfully when the iPhone has Find my iPhone search mode enabled. Then access the icloud address later, log in to a compatible Apple account with the phone. Select the All Devices button to display the full list of required applications. Next select iPhone (iPad or iPod - the product contains the passcode to be deleted).

Next, select the Erase button to remove the Passcode. Finally, use the latest backup to get back the previous data. Thus iPhone phone users can access the device without a password.

Use Recovery mode

If your iPhone has been backed up and synced or doesn't store important information and the above methods don't work, try using Recovery mode immediately.

Technology experts believe that Recovery mode is one of the simple solutions to help users solve the above problem easily. Recovery mode will erase all the data in the device and bring the phone back to the beginning. To do this, just prepare a charging cable, a computer (running MacOS or Windows) with iTunes installed with the latest update.

Then power off the device and exit the connection between iPhone and computer. Hold down the Home key, reconnect to the computer. Wait for a few moments, the phone will appear Connect to iTunes message on the screen, then release the Home key, select OK and select Restore iPhone and then find the nearest backup to perform.

You finished reading the article "**iPhone fix tips are disabled**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.