

# List the default password of D-Link router

D-Link routers almost never require the default password and often use the default IP address of 192.168.0.1 but there are exceptions, as you can see in the table below.

D-Link routers almost never require the default password and often use the default IP address of **192.168.0.1** but there are exceptions, as you can see in the table below.

**Important note:** Don't forget to reset your router's password after you log in.

See below the table for more help, if the default data below doesn't work, you don't see your D-Link device or you have any other questions.

## D-Link default password (valid until November 2018)



D-Link Model	Default username	Name	Default password	The default IP address
COVR-3902	None	None	None	192.168.0.1
COVR-C1203	None	None	None	192.168.0.1
DAP-1350	admin	No	192.168.0.50	DFL-300
admin	admin	192.168.0.1	DGL-4100	None
None	None	192.168.0.1	DGL-4300	No
No	No	192.168.0.1	DGL-4500	Admin
No	192.168.0.1	DHP-1320	Admin	No
192.168.0.1	DHP-	1565	Admin	None
192.168.0.1	DSL-2750U	admin	admin	192.168.1.1
192.168.1.1	DI-514	admin	No	192.168.0.1
192.168.0.1	DI-524	admin	No	192.168.0.1
192.168.0.1	DI-604	admin	No	192.168.0.1
192.168.0.1	DI-614	+	admin	No
192.168.0.1	DI-624	admin	No	192.168.0.1
192.168.0.1	DI-624M	admin	No	192.168.0.1
192.168.0.1	DI-624S	admin	No	192.168.0.1
192.168.0.1	DI-634M	<sup>1</sup>	admin	No
192.168.0.1	DI-634M	<sup>1</sup>	user	No
192.168.0.1	DI-701	<sup>2</sup>	None	No
192.168.0.1	DI-701	<sup>2</sup>	No	year2000
192.168.0.1	DI-704	No	admin	192.168.0.1
192.168.0.1	DI-704P	No	c ó	192.168.0.1
192.168.0.1	admin	admin	DI-704UP	No
192.168.0.1	DI-707	No	admin	192.168.0.1
192.168.0.1	DI-707P			

admin No 192.168.0.1 DI-711 admin No 192.168.0.1 DI-713 No admin 192.168.0.1 No admin 192.168.0.1 DI-713P No 192.168.0.1 admin DI-714 admin No 192.168.0.1 DI-714P + admin No 192.168.0.1 DI-724GU Admin No 192.168.0.1 DI-724U admin No 192.168.0.1 DI-754 admin No There is 192.168.0.1 DI-764 admin No 192.168.0.1 DI-774 admin No 192.168.0.1 DI-784 admin No 192.168.0.1 DI-804 admin No 192.168.0.1 DI-804HV admin No 192.168.0.1 DI -804V admin No 192.168.0.1 DI-808HV admin No 192.168.0.1 DI-824VUP admin No 192.168.0.1 DI-LB604 admin No 192.168.0.1 DIR-130 admin No 192.168.0.1 DIR-330 admin No 192.168.0.1 DIR-412 Admin No 192.168.0.1 DIR-450 admin No 192.168.0.1 DIR-451 admin No 192.168.0.1 DIR-501 admin No 192.168.0.1 DIR-505 Admin Dry There is 192.168.0.1 DIR-505L Admin No 192.168.0.1 DIR-506L admin No 192.168.0.1 DIR-510L No No 192.168.0.1 DIR-515 admin No 192.168.0.1 DIR-600 admin No 192.168. 0.1 DIR-600L admin No 192.168.0.1 DIR-601 Admin No 192.168.0.1 DIR-605 admin No 192.168.0.1 DIR-605L admin No 192.168.0.1 DIR-615 Admin No 192.168.0.1 DIR-625 Admin No 192.168.0.1 DIR-626L Admin No 192.168.0.1 DIR-628 Admin No 192.168.0.1 DIR-635 Admin No 192.168.0.1 DIR-636L Admin No 192.168.0.1 DIR-645 Admin No 192.168.0.1 DIR-651 Admin No 192.168.0.1 DIR-655 Admin No 192.168.0.1 DIR-657 Admin No 192.168.0.1 DIR-660 Admin No 192.168.0.1 DIR-665 Admin No 192.168.0.1 DIR-685 Admin No DIR-808L Admin No 192.168.0.1 DIR-810L Admin No 192.168.0.1 DIR-813 Admin No 192.168.0.1 DIR-815 Admin No 192.168.0.1 DIR-8 17LW Admin No 192.168.0.1 DIR-817LW / D Admin No 192.168.0.1 DIR-818LW Admin No 192.168.0.1 DIR-820L Admin No 192.168.0.1 DIR-822 admin No 192.168.0.1 DIR-825 Admin No DIR-826L Admin No 192.168.0.1 DIR-827 Admin No 192.168.0.1 DIR-830L admin No 192.168.0.1 DIR-835 Admin No 192.168.0.1 DIR-836L Admin No 192.168.0.1 DIR -842 admin No 192.168.0.1 DIR-850L admin No 192.168.0.1 DIR-855 Admin No 192.168.0.1 DIR-855L admin No 192.168.0.1 DIR-857 Admin No 192.168.0.1 DIR-859 Admin No 192.168.0.1 DIR-860L admin No 192.168.0.1 DIR-865L admin No 192.168.0.1 DIR-866L admin No 192.168.0.1 DIR-867 admin No 192.168.0.1 DIR-868L admin No 192.168.0.1 DIR- 878 admin No 192.168.0.1 DIR-879 admin No 192.168.0.1 DIR-880L Admin No 192.168.0.1 DIR-882 admin No 192.168.0.1 DIR-885L / R admin No DIR-890L / R Admin 192.168.0.1 No 192.168.0.1 DIR-895L / R Admin No 192.168.0.1 DSA-3100<sup>3</sup> admin admin 192.168.0.40 DSA-3100<sup>3</sup> manager manager 192.168.0.40 DSA-3200 admin admin 192.168 .0.40 DSA-5100<sup>3</sup> admin admin 192.168.0.40 DSA-5100<sup>3</sup> manager manager 192.168.0.40 DSR-1000 admin admin 192.168.10.1 DSR-1000N admin admin 192.168.10.1 DSR-250N admin admin 192.168.10.1 DSR-500 admin admin 192.168.10.1 DSR-500 admin admin 192.168.10.1 DSR-500N admin admin 192.168.10.1 EBR-2310 admin No 192.168.0.1 GO-RT-N300 Admin No 192.168.0.1 KR-1 admin No 192.168.0.1 TM-G5240 No admin 192.168.0.1 WBR- 1310 admin No 192.168.0.1 WBR-2310 admin No 192.168.0.1

1) D-Link DI-634M Router has two default access accounts, one administrative account (user name is **admin**) - which you should use to manage the router - and a user-level account ( User name is **user**) can be used to view data but not make changes.

2) The D-Link DI-701 router has an administrator-level default account (no username or password is required), as well as another administrator-level account for ISPs called **Super Admin** (no person name) Use the **year2000** password ) , giving the admin the ability to set user limits via the **usrlimit** command , available in the terminal mode of the router.

3) D-Link routers, DSA-3100 & DS-5100, have the default administrator account (**admin / admin**) as well as the default "**manager**" **manager / manager account**) are restricted in adding and managing User access account.

## When D-Link default password or username does not work

For D-Link routers or any other network device, if the default password has been changed and you do not know what it is, regret to inform you that you cannot work with your device anymore.

The only solution is to reset the entire D-Link device to its original settings, reset the password to default and delete all wireless networks or other settings.

Performing to restore the original settings on D-Link router is quite easy. Turn on the device, press and hold the **Reset** button (usually on the back of the device) with a paper clip or small pen tip for 10 seconds and then release. Wait a few more minutes for the router to finish restarting.

If the factory reset does not work or you cannot find the reset button, see the user guide included with your device for more details. The PDF version of the device user guide can be found at D-Link Support.

## When the default IP address of D-Link router does not work

Assuming that the D-Link router is turned on and connected to your network, but the default IP address listed above does not work, try opening a browser window and connecting to **http:// dlinkrouterWXYZ** with **WXYZ** is the last four characters in the device's MAC address.

All D-Link devices have MAC addresses printed on the sticker located on the back of the device. So, for example, if the MAC address of your D-Link router is **13-C8-34-35-BA-30**, go to **http:// dlinkrouterBA30** to access your router.

If the tip does not work and your D-Link router is connected to the computer, the default gateway configured will almost always be the same as the router's IP address.

If you need more help accessing or troubleshooting problems related to D-Link routers or have other general questions about passwords and default network data, leave comments in the comments section below!

Good luck!

See more:

1. List the default password of the Linksys router
2. List the default password of Cisco routers and switches
3. List the default password of NETGEAR router

You finished reading the article "**List the default password of D-Link router**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.