

Printer has white stripes - Causes and solutions to print with white stripes


Your printout has white stripes, not as good as you would like. The article tells you the cause of this error and how to fix the problem of the printer with white stripes, click to see now!

Your prints will not be pretty if printed out and found guilty blurry, black stripes or white stripes, these errors are common with firms printers like the Canon printers , printer HP , Brother printers , printer Samsung, Epson printer. The article shows how to fix the printer error with white stripes, follow along!

1. The phenomenon of the printer has white streaks

When you print documents in a laptop or computer , the printout has a white streak, which is shown by the following conditions:

- The print is not uniform, white one or more places.
- A vertical white streak runs the length of the text.
- White almost whole text.



2. Cause the printer has white streaks

Usually, you would think that the first error when the printer makes this error is because the printer 's ink is running low, however, the main cause is due to a damaged drum. This error can occur because during use, you

use paper with high roughness and friction.

The drum is the part in the ink cartridge that is responsible for printing text on the paper when the ink rolls through. Drums, or Drums, are made up of several layers of paint, if this paint is scratched, the drum will fail.



In addition, the printer drum is worn out because you did not check the print paper carefully. Most likely they are stuck with pins or other foreign objects, when printing, they get caught in the printer drum and damage this part. This is one of the reasons why prints have white streaks.

Besides, the following factors can also cause the above error:

- Ink used is not up to standard.
- Ink cartridges are not replaced in time when the machine is about to run out of ink.
- You have not regularly cleaned the printer.



3. How to fix a printer with white streaks

How to fix the printer error with white streaks is also quite simple, but you must be very attentive and careful. If you need to determine if the error is caused by the drum, you can take out the cartridge and see the Drum bar (usually painted blue). If this bar is scratched, your printer has encountered this error.

Once you've determined that the problem is caused by a faulty printer drum, you need to replace the drum with a new one. In case this blue paint is peeling or scratched, you should replace the new part soon to avoid this error repeated many times. To ensure quality and be consulted carefully, you should trade at reputable establishments.



Avoid leaving the printer drum scratched as this will damage the drum

In addition, you should also check that your cartridges are empty to be replaced, and be aware that genuine ink is used to ensure the best quality. Besides, you also need to pay attention to clean the printer regularly so that the printer can work at its best.



4. The printer is full of white text

Magnetic shaft is worn, damaged

When you hear about the worn or damaged assembly of a device, you can understand that the device has been used for too long to lead to this condition. Or, when the magnetic shaft is worn or damaged, it is possible that you did the wrong thing to remove the paper when the printer jammed.

If you encounter this error, the only way you can do it is to replace the magnetic shaft with a new one. When buying components, you need to pay special attention to the quality of the product. Therefore, to ensure, you need to go to reputable facilities for timely advice and support.



In case of blocked printer nozzles

During use, users will pay little attention to the nozzle, so they will rarely go for maintenance. There are many reasons that can explain this situation as follows:

- The printer is rarely used or you use the wrong ink, use the ink from the same brand that changes continuously.
- The driver installed is not compatible with the printer, causing the printer to not print.
- A damaged ink cartridge causes a white full-text error.

When you encounter this error, you can follow the instructions below to resolve it:

Step 1: Remove the nozzle of the inkjet printer.



The printer nozzle pins will be exposed when the ink cartridge is completely removed

Step 2: Pour 1 amount of printer spray cleaner into a clean bowl. Immerse the bottom of the nozzle in water, about 2-3mm. You can soak for a few hours or soak until the next day, be careful not to let the insects fall into the bowl of water!



The upper part of the cable connector must not come into contact with washing water

Step 3: Use a dedicated nozzle washing device to gently shake the nozzle, repeat this process 2-3 times.



Thoroughly clean the printer nozzles

Step 4: Using a syringe to suck up the washing water, press it into the ink supply connector on the nozzle. If the water line is straight, the nozzle is almost completely open. If the water line is not straight, you need to continue rinsing 2-3 times.



The nozzle is no longer clogged when the cylinder hose sprays water in a straight line

5. The printer prints to white paper

Similar to the causes of the printer error with white streaks, the printer prints white paper because the printer is out of ink, the magnetic shaft is damaged, the driver is not installed properly, the printer's ink cartridge or inkjet head is faulty. disabled (for inkjet printers).



The article shows how to fix the printer error with white streaks. Hope the article will help you to handle the error, see you in the next article.

You finished reading the article "**Printer has white stripes - Causes and solutions to print with white stripes**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.