

Proper maintenance and cleaning of tree fans

After a long time of use in the summer months, we will need to clean the fan and maintain it for next summer. And the proper maintenance of the fan also extends the life of the fan

Maintenance of electric fans and fan cleaning is essential to help fans work properly, especially after a period of unused winter. Besides, the fan life is also prolonged when we perform proper cleaning and maintenance. In the following article, we will guide you step by step to properly clean and maintain the fan.

Step 1: Remove fan parts:

Unplug the fan, bring the fan to an open area that is easy to clean and avoid soil contamination. Remove each part and component of the fan from the fan cage, the fan blade in order to help you easily install the fan. We must unplug the power to ensure safety and not cause electric shock in the process of cleaning the fan. This is similar to a refrigerator, when you want to clean, clean or maintain the cabinet, the first thing you need to do is unplug.



Step 2: Cleaning the fan and fan blades:

Fan cage must be cleaned regularly because during use it is easy to get dust, dirt and loss of aesthetic. Electrical fan maintenance cannot be bypassed by cleaning the fan and fan blades. You can wipe the impeller with a damp cloth with soap and then use a dry towel to wipe it off, or remove the fan blades completely to wash with soap and dry.



To clean the internal parts, first remove the bearing, the rear gear box fan out. Use a towel to clean it, apply grease to moving parts. Note not to let water spill into electronic components.

For ceiling fans, to maintain the electric fan, use a soft brush to sweep the dust and use the soft cloth to wipe the fan. If you find it too inconvenient and laborious to clean common ceiling fans, install a Panasonic F-56MPG ceiling fan with energy saving technology that is easy to clean when used. The fan has a modern and luxurious design, including 4, 30cm long propellers, 6.5kg weight, easy to install and use, made from high-quality materials, minimizing dust adhesion, not much loss effort to clean and maintain the fan. Panasonic F-56MPG ceiling fan has timer function and safety switch to ensure efficiency, power saving and safe to use. This ceiling fan maintenance is also much easier.



Step 3: Maintenance of electric fans for the reel:

After cleaning the fan blades and fan cage, you should open the gear cover on the back to check the oil. Then open the cover with the shaft seal, clean the 2 ends of the shaft, put the oil in it.

Next, you drop a few drops of motor oil into silver fan, turn slightly so that the motor operates smoothly and more durable.



Step 4: Install parts and parts:

Install each part and component in reverse order when removing to maintain the electric fan. After installation is complete, try plugging in the power outlet to check effectively. Check electrical wires, grips and electrical outlets.

Panasonic F409MB wall fan with compact design, suitable for small spaces, 60W operating capacity gives you a cool airflow to spread every corner, Remote control remote makes it easy to adjust and schedule . Panasonic F409MB wall fans are easy to disassemble, you can clean easily to improve efficiency, extend electric fan life.



The maintenance of the fan before and after a long period of use will help the fan operate with high efficiency, longer fan life. In the cleaning process, we also need proper hygiene, to avoid damage to or damage to the parts on the electric fan.

Hope few posts above useful to you!

You finished reading the article "**Proper maintenance and cleaning of tree fans**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.