

# Steps to connect wifi on Panasonic Smart TV tivi

Most Panasonic smart TVs support wifi connection so that users can use and experience many useful features, programs and information not only in the country but also abroad.

Smart TV Panasonic supports wifi connection, helping you to experience more attractive entertainment applications and access to many other information channels in the world. Please refer to the steps to conduct wifi connection on Panasonic TV below!



## Set up wifi on Panasonic Smart TV

To connect to wifi on a Panasonic TV, do the following:


**Step 1:** Select the **Menu** button on the TV remote.



**Step 2:** Select **Network** -> Select **Network Connection** . At this time, the TV will scan for all wifi networks around the TV.



**Step 3:** Select **the wifi name** you want to connect to and enter the password.



**Step 4:** Press **Return** on the TV remote to start connecting to the TV network.

**Step 5:** After the TV connects to the Internet successfully, you can try any website to **check the internet connection** .

**Note:**

1. If the wifi you want to connect to does not have a password, you can skip this step.
2. If the TV says connected but still cannot access the network using a web browser or an application that requires an Internet connection, use a smart phone or another mobile device to check your home network connection.
3. The network speed depends on your home signal line.

With just 5 simple steps, it doesn't take much time, you can connect to wifi on Panasonic TV to be able to access any program you want. Good luck!

You finished reading the article "**Steps to connect wifi on Panasonic Smart TV tivi**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.

---