

The television screen blinks continuously, cause and remedy

Before intending to bring the TV to repair, try to find out the cause of the error and how to fix the TV flashing according to the instructions below.

The phenomenon of television screens suddenly blinking constantly is a problem many users encounter. When falling into this situation, television is almost impossible to watch or very difficult to see. However, before you intend to bring the TV to repair, try to find out the cause of the error and how to fix the television flashing according to the instructions below.

1. Fix some common errors on Toshiba TV
2. Judge the error on Sony TV via flashing indicator
3. TV does not access YouTube / Facebook, this is the cause and remedy

1. The TV expression is blinking continuously

When you are using the television, suddenly the screen darkens or blackens and lights up again, like you turn on and off the TV continuously, you can conclude that your television screen is having a flashing error.

2. The staff and fix the TV screen are blinking

The TV with a blinking error or distorted TV image is most likely due to the connector of the device connected to the TV such as a DVD player, a digital TV receiver, a video game machine, etc. Trouble. So, check the connection ports, jacks, . If the loose wire is attached or replaced, it detects a rusted, damaged joint.



If you are sure that the devices connected to the TV are not problematic, the chances are high that your home power source is unstable, or maybe in the rainy days the power source will change abnormally, which will cause the TV to meet Continuous flashing error. Consider to ensure that your power source is stable, avoiding the situation that the television screen is blinking and affecting the experience.



In addition, it is not possible to exclude the possibility that the television has been screened because the details that support the light and television playback (such as LED lights, screen light bulbs) have been damaged. Handling this error, there is no other way that you must bring the TV to its warranty center (if it is still within the warranty period), or go to reputable TV repair addresses (if no warranty is available). to replace the screen light bulb.



One more way to fix a continuous blinking TV error that you can perform at home, is to unplug the TV, then press and hold the power button of the TV for a few seconds. Leave the TV on for a minute or two and plug in the power and turn on the television.



Recently, there are some reasons as well as how to fix the error of the TV screen flashing continuously, hope that the above information will help you quickly fix the TV errors that are encountered and do not interrupt the viewing process.

Good luck!

See more:

1. 3 mistakes when turning off the TV almost everyone has
2. Can singing karaoke online on Smart TV?
3. Instructions to block ads on Smart TV

You finished reading the article "**The television screen blinks continuously, cause and remedy**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.

