


6 simple and effective tips to fix laptop with lost WiFi

There are many reasons for the laptop's WiFi loss, affecting your work. Check out the article to know how to fix a laptop that loses WiFi.

When you use a laptop, you will often encounter a situation where you cannot connect to WiFi or even lose WiFi. There are many reasons that lead to this uncomfortable situation, but almost not everyone knows how to fix it. This article will help you fix your laptop without WiFi simply and effectively at home.



1. Restart the machine and the Router

During use, it is possible that your laptop or Router has been in conflict. But it will take a lot of time to check each device and if both are in conflict, it will be more difficult to handle if you start each. Please restart both and then try to connect again.




2. Check connection mode ??

Many laptops give you a shortcut to proactively adjust your network connection. Check your device's WiFi fast toggle and airplane mode to make sure that WiFi connectivity is still on.




3. Check the connection in Control Panel


You access the **Control Panel** by **searching for the application on the Taskbar** . With Control Panel You can drill down inside the network card.



Then, you find the **Change Adapter Setting** section inside the **Network and Sharing Center** section.




Finally if You see the **network card is disabled (it's grayed out)**, You **must right-click** and select **Enable** .




4. Remove WiFi connection

You may have problems with WiFi's password processing. Try opening the **WiFi connection** section and **right-clicking on the** currently connected **WiFi** . Then you choose **Forget** and reconnect to WiFi from the beginning.




5. Check the driver of the network card

You need to open **Device Manager** on the system by typing the same words into the search bar on the **Taskbar** .




Then you find the **Network Adapter** section , right-click and select **Uninstall** to delete the **old Driver** . After that, you let the machine **update the new Driver** .




5. Refresh IP address


Use **Command Prompt** to fix IP errors , search for **Cmd** on the **Taskbar** . Then, Right-click or select on the search bar the line **Run as administrator**.



Next, type the command line **ipconfig /release** and select **Enter** .



Finally, type the command line **ipconfig /renew** so that the machine can **refresh the IP**.



6. Do not turn on battery saving mode on laptops

You should never turn on economizer mode on your laptop. In this mode, your devices will have to reduce brightness, performance and connections. To turn off this mode, go to **the battery section on the laptop and drag the adjustment bar to the center**.



How do you see these ways? Thank you very much for viewing the article.

You finished reading the article "**6 simple and effective tips to fix laptop with lost WiFi**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.