

# How to reset wifi when forgot password

Many people want to change the wifi password to another more difficult password sequence to avoid too many people accessing and using it, leading to poor wifi. However, because of that, it can cause you to accidentally forget the WiFi password.

So what should you do now? That's in this case, what you need to do now is reset WiFi. So how is wifi reset done? All will be revealed in the article below, don't miss it.

## Find the password on the router

First of all, you should perform the steps below to see if you can retrieve the wifi password on the router:

Step 1: Remember carefully whether you have used the default password of the router or not? Because new routers often have a default password preset. So if you need to recall, see if you have used this password.

Step 2: Find the password on the router. Usually these initial default passwords will be printed on the sticker on the back or bottom of the product. The password will be located near the 'SSID' header and is usually a string consisting of: uppercase, lowercase letters and numbers.



If you don't see a password like this on the label, check your router's documentation - a place manufacturers often use to enter the default password, or you can check the box. product.

## Reset wifi with the reset button on the router

You need to determine the correct location of the reset button on the WiFi router. For TP Link series, the button position will be located on the port side of the modem. Once you have located the correct position, use a small, pointed object and then press and hold the reset button for about 10 seconds. When the lights turn on at the same time and then turn off, release your hand and wait for it to restart.



This method you can use for all other modem brands, not only TP Link series.

## **Method of resetting wifi on modem configuration page**

First, you need to turn on the router or make sure the router is turned on. Then start the process of rebooting. Default IP address for login is 192.168.1.1 and 192.168.0.1, or <http://tplinklogin.net/> for login and username and password are all set as: admin. Once you know the information After that, let's start with the steps:

Step 1: Click on the TP-Link WiFi router and modem configuration page, then log in to your account.

Step 2: Go to System Tools > Reboot > Reboot then click OK to reset WiFi TP Link.

It should be noted, if you want to delete all the settings you have created and reset the TP Link router to return them to the state they were in when you first bought them, please do the following: go to Factory Defaults > Restore to reboot and reset the TP-Link router.

## **Call the support switchboard**

If you use all the other methods but you still can't find a way to reset your wifi, the last option for you is thanks to the support of the switchboard. This also brings more certainty for those who are not tech-savvy and do not want the steps to be disturbed when they perform the operation. With customer care service being focused as today, all businesses in general and internet network providers in particular are very active.

Some notes you need to pay attention to before resetting wifi is that resetting the router will erase all current settings of the router and return it to its factory default state. Above we have sent you methods so that you can reset wifi. Hope the above information will be useful to you and help you get the best experience in work and daily life. Hope you have a very productive day.

You finished reading the article "**How to reset wifi when forgot password**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.

---