

How to use the most simple, detailed child locator Q50

Equipped with a positioning clock is a very necessary job to help parents feel secure to work, go to work away from home and still monitor their children's activities. In this article, Quantum will guide you how to use the positioning clock Q50 - one of the products most trusted by parents today.

Equipped with a positioning clock is a very necessary job to help parents feel secure to work, go to work away from home and still monitor their children's activities. In this article, Quantum will guide you **how to use the positioning clock Q50** - one of the products most trusted by parents today.

main content

1. Learn general about the positioning meter Q50
2. Instructions on how to use the locator Q50 is simple
 1. Introducing the function buttons of the watch Q50
 2. How to use the function buttons of the clock
3. Where to buy a locator Q50 where is the quality guaranteed?



Learn general about the positioning meter Q50

The Q50 is a brand from the Wonlex brand - a manufacturer of top-of-the-range child watch lines in China.

Its products are sold globally and favored in the domestic market, America, Europe, Asia, Southeast Asia . Currently, Wonlex is the most trusted brand of locating watches at Vietnam market because of good quality and affordable price.

General characteristics of Wonlex Q50 locator:

1. The product is designed with a 0.96-inch monochrome screen with easy-to-use mechanical keys for even illiterate children. The device is suitable for children aged 5-6 years and older.
2. The watch is made of plastic material combined with flexible silicon that is friendly to your baby's sensitive skin and persists with time. At the same time these materials are also very light, the weight of the product is only about 40 grams so it does not cause fatigue or discomfort for the baby.
3. The product colors are quite diverse and can be suitable for both boys and girls
4. Wonlex Q50 is equipped with 2-way call function. Children can contact up to 15 stored phone numbers and contact up to 3 phone numbers installed when pressing the SOS button for 3 seconds.
5. Parents can manage to block strange numbers so that strangers don't bother or take advantage of children
6. Positioning mode via GPS and LBS allows parents to set a safe area for children within a radius of 200m - 2km
7. Can record the number of steps, calorie consumption, movement distance, amount of sleep . help parents can keep track of their health situation.
8. You can set non-disturbing mode and alarm timer available for your baby
9. High security mode in case the baby forgets or loses the device, the picker cannot use it without an account.
10. The product has a reference price of VND 469,000 and a 12-month warranty.



Instructions on how to use the locator Q50 is simple

To use the smart locator Q50 you need to install the Setracker2 application for them.

Refer to the installation here.

Introducing the function buttons of the watch Q50

You can observe 2 sides of the Q50 clock with a total of 5 different buttons. These buttons include:

1. On the left: There are 2 buttons including SOS button and battery charging port.
2. On the right: There are 3 buttons which are the SOS call button number 1, power button and SOS call button No. 2.



How to use the function buttons of the clock

1. With charging slot

You can use the android operating system chargers such as Samsung, Sony . or IOS operating system like iphone to attach to the watch charger cord.

Note: To ensure battery life, it is best to use a charging cup with 5V - 1A or 5V - 0.5A capacity.

2. With SOS call button

If your baby needs to make an emergency call to the installed phone number, they just need to hold the SOS button for about 3 seconds. At this time, the watch will send an SOS command to the software and continue making calls to the SOS numbers in the following order:

1. First, the watch calls for SOS number 1, if SOS 1 does not listen, the watch will continue to call SOS number 2. If SOS 2 does not listen, the watch will call SOS number 3.
2. If all 3 numbers are not heard, the meter will call again 1 in the original order

Note:

1. The SOS button is also the button to catch the phone, when someone calls, just press and release the SOS button to receive the call.

2. When receiving a voice message, just press and release the SOS button to listen to the message.

3. SOS 1 and SOS call button 2

If you press and hold for about 3 seconds on 1 of these 2 buttons, the watch will call the phone number saved in the SOS section. Press and hold down 1 to call SOS number 1, press and hold down button 2 will call SOS number 2. (SOS number set by parents themselves)

Note:

1. In addition, when you press and release the number 2 button, the contacts will appear.
2. Press the 1 button to move up, 2 scroll down.
3. When selecting the contact, hold down the SOS button for about 3 seconds to call.
4. When receiving a call, you can press 1 to increase the volume and press 2 to decrease the volume.

4. Power button

When the clock is not attached to the sim, you can use this Power button to turn off the power. After attaching the sim and connecting to the account, the Power button has the function to send voice messages.

You just need to press and hold, the voice message will be sent to the software.

With this Q50 positioning clock, hopefully you will be able to confidently manipulate and quickly experience their interesting features.

Where to buy a locator Q50 where is the quality guaranteed?

Currently, there are many distribution addresses for children locating products on the market, in which Q50 is also sold quite widely.

This leads to users also quite confused when choosing. So how to buy a quality Q50 watch?

Suggestions for you are buying products at the website: **META.vn**. This is a unit specializing in trading of smart watches, locating watches with over 10 years of experience. When you buy goods here, you will always have a feeling of peace of mind because 100% of goods have clear proof of origin. Besides, the warranty mode with super attractive promotions, after-sales programs.

Contact now to own quality products:

1. Hanoi: 56 Duy Tan - Dich Vong Hau - Cau Giay. Hotline: **024.3568.6969**
2. Ho Chi Minh City: 716-718 Dien Bien Phu - Ward 10 - District 10. Hotline: **028.3833.3366**

>>> More references:

1. Young lost notification clock
2. What is the best child positioning meter?
3. Top 5 cheap kids phone watches with smart positioning function

You finished reading the article "**How to use the most simple, detailed child locator Q50**" edited by the [TipsMake](#) team. We hope this article has provided you with many useful tech tips and tricks. You can search for similar articles on tips and guides. Thank you for reading and for following us regularly.

